



NOTE:

1. MOUNT COMPRESSED AIR LINE FROM COMPRESSOR TO FILTERS ALONG WALL. PROVIDE HOUSEKEEPING PAD FOR COMPRESSOR.
2. MOUNT SAMPLING LINE ALONG WALL.
3. COORDINATE MONORAIL/CRANE LOCATION AND ELEVATION WITH BLOWER SUPPLIER.
4. REFER TO MECHANICAL DRAWINGS FOR CONTINUATION OF DRAIN LINES.

APEGM
Certificate of Authorization
Earth Tech Canada Inc.
No. 730 Expiry: April 30, 2007

01	291-2006 ADDENDUM 3	06/07/12	LAE
00	ISSUED FOR TENDER	06/05/15	GLG
NO.	REVISIONS	DATE	BY

EarthTech
A Tyco International Ltd. Company

DESIGNED BY	YL	CHECKED BY	SB
DRAWN BY	SRP	APPROVED BY	JEH
SCALE:	AS NOTED	RELEASED FOR CONSTRUCTION BY:	K. MARTENS
DATE	2006/01/16	DATE	2006/05/15

ENGINEER'S SEAL
ORIGINAL SIGNED BY
J.E. HUTCHISON
2006/05/15
CONSULTANT DRAWING NO.
P15.01

THE CITY OF WINNIPEG
WATER AND WASTE DEPARTMENT
ENGINEERING DIVISION

NEWPCC CENTRATE NUTRIENT TREATMENT
NITROGEN REMOVAL FACILITY

PROCESS
BLOWER ROOM & SAMPLING ROOM
PLAN & SECTIONS

CITY FILE NUMBER	
SHEET OF	
CITY DRAWING NUMBER	