



DEMOLITION NOTES

1. REMOVE ALL WALLS & CEILING AS NOTED WITH DASHED LINES EXCEPT THE WALL SUPPORTING THE FIRE HOSE CABINET
2. REMOVE CEILING TILES, LIGHTS, AND MECHANICAL ITEMS. REUSE IF POSSIBLE
3. REMOVE DOORS, FRAME, HARDWARE AND GLASS AND REUSE AS NOTED OR TURN OVER TO THE CLIENT FOR STORAGE
4. REMOVE CARPET BASE AND REUSE IF POSSIBLE. REMOVE CARPET TILE AND GLUE FROM FLOOR

DEMOLITION PLAN AREA A

SCALE: 1:100



13 ROSEWARNE AVE WINNIPEG, MB.
R2M 0V8
P 204 233-9159 F 237-4769
malvine@synergyinteriors.com

CLIENT CITY OF WINNIPEG, RENOVATIONS TO ENGINEERING & RECORDS STORAGE AREAS WATER & WASTE OFFICES
1199 PACIFIC AVE.

C.C.

DATE NOV 2009	SCALE	REVISIONS
DRAWN BY M.G.	CHECKED BY M.G.	

DWG
A-3