

Pedra Cap to be predrilled and screwed to Base course using screws. Screws shall be Stainless Steel or Ceramic Coated and appoved for use with ACQ treated wood. Screws to extend into timber base a minimum of 5 cm and be countersunk into pedra. Two screws are to be placed at each end and every 60 cm alonge length. Strait sections of pedra are to be butt jointed.

Top Plan

Sod to be below top oftimbers as per grading drawing. Sod is to drain away from timbers. Minimum 1/2 of bottom tier

Compacted 20 mm ø

down Limestone



4/23/10

2

No.

Drawing No.

4/23/10

Date