

ection
NOTES: Install catch basins with solid covers when used expressly as cleanouts at the high end of any drain line.
Only install catch basins with the appropriate number of inlets to suit the situation.
Install top of catch basin 25mm below finish grade.
- Mineral Sod / PVC riser pipe (Cut to suit as required)
Varies
Compacted subgrade
Profile

2016	Scale: As specified North:	Drawn: TK Checked: DG Proj. No.: 16.09	Date: Apr. 11, 2016 Revisions: July 5, 2016	Drawing No.: L3
------	----------------------------------	---	--	--------------------