

# **APPENDIX 'I'**

## **MMA MARKINGS APPLICATION**

# APPLICATION INSTRUCTIONS

## MMAX AREA MARKINGS

**Overview:**

MMAX AREA MARKINGS conveniently combine state-of-the-art Methyl Methacrylate resins with hardwearing aggregate and premium pigments to deliver an extremely durable, highly visible and color stable lane delineation treatment that meets the non-slip requirements needed for pedestrians, cyclists and vehicles.

MMAX AREA MARKINGS are mixed onsite and is distributed on to the pavement substrate using squeegees and cure in a wide range of temperatures with predictable back to traffic times of 20-60 minutes.

**EQUIPMENT:**

The following items are needed during the different stages of application.

<u>Surface prep &amp; layout</u>	<u>Mixing</u>	<u>Installation</u>	<u>Clean up</u>
Stiff broom	High speed / torque drill (with power source / spare batteries)	Long handled squeegees	Solvent resistant gloves
Blower / compressed air	Mixing paddles	Spare rubber squeegee blades	Safety glasses
Measuring tape	Measuring cup	Straight hand trowels	Acetone
Chalk line	Small tarp	Long handled roller cages	Large cleaning tub
Marking crayons	Screw driver/bucket opener	Rollers - med. nap (5 per 1000 sqft)	Solvent resistant brushes
Duct tape	Utility knife		Cloth rags
Roofing paper	Misc tools		Trash bags

**GENERAL REQUIREMENTS:**

**SURFACE:** MMAX AREA MARKINGS can be applied on stable, well compacted asphalt or non-bituminous concrete surfaces, such as Portland cement concrete. New substrates should be allowed to age harden or cure for minimum 15 days (asphalt) to 30 days (concrete) before installation. Pavement surface must be completely free of dirt, debris, moisture, curing compounds and other contaminants that can affect adhesion. Chemical contaminants such as vehicle fluids must be removed well in advance using a degreasing solution and power washer, ensuring all residues are removed. Existing pavement markings within the application area may be removed by gently sandblasting, shot-blasting, water-blasting or grinding making sure that minimal damage is done to the substrate. Aged surfaces containing reflective cracking should be repaired, or reflective cracking should be expected to re-appear after installation.

**MATERIAL:** Avoid extreme storage temperatures. Keep materials in dry, protected areas, between 40°F – 80°F. Keep out of direct sunlight and protected from open flame. Use within six months of receipt.

**TEMPERATURE:** Ambient and surface temperatures for installation should be between 40-100°F, and should be 5°F above the dew point temperature. There should also be less than 75% relative humidity when installing MMAX AREA MARKINGS.

**SAFETY PRECAUTIONS:**

Review MSDS for MMAX AREA MARKING products before usage.

**INSTRUCTIONS FOR APPLICATION:**

**Surface Prep:** Clean the intended application area thoroughly. All loose particles, dirt, sand dust, etc. must be removed. Concrete surfaces should be wire brushed, at minimum. Sweep completely. Use a power blower or compressed air. Clean areas containing chemical contaminants such as vehicle fluids, using a degreasing solution. Proper removal of contaminants and degreasing solution are necessary well in advance of the application.

## APPLICATION INSTRUCTIONS

### MMAX AREA MARKINGS

**Masking:** Using duct tape and roofing paper, mask off perimeter of area to be colored, as well as any object not to be colored such as manhole covers, drains and existing markings.

**Mixing:** Add the supplied 25.7 lbs of MMAX AREA MARKING Aggregate into the 2 gallons MMAX AREA MARKING Resin and mix with clean mixing paddle, using a high speed, high torque drill. Add the recommended amount of powder catalyst, based on ambient and pavement temperature (Table 1), and mix thoroughly.

After adding the catalyst, MMAX AREA MARKING will start curing and must be applied to the pavement immediately. There will be 4 to 10 minute working time, which is temperature dependent.

Material will mix to approximately 2.79 gallons (10.55 liters), weigh 52 lbs and cover 45-50 sqft @ 90 mils.

Caution: Clean the mixing paddle between uses or understand that material will immediately initiate curing if previously exposed to catalyzed material (and not cleaned).

Table 1: Recommended catalyst by temperature range:

< 70°F / 18°C	lbs (kg)	.51 (.23)
	fl oz (liters)	12 (.365)
70-90°F / 18-32°C	lbs (kg)	0.26 (.12)
	fl oz (liters)	6 (.185)
> 90°F / 32°C	lbs (kg)	0.13 (.06)
	fl oz (liters)	3 (.09)

**Installation:** Immediately, pour mixed material on to pavement to be treated and use a squeegee to evenly distribute at a coverage rate of 16-18 sq. ft. per gallon, or 45-50 sq. ft. per pail. Pre-measuring / pre-marking can assist to ensure proper coverage. Use trowel in small, tight areas where squeegee cannot effectively be used. After rough distribution with squeegee, back roll material (one direction only) to remove working lines created with squeegee and create a consistent, anti-slip texture. Roller will last longer during continuous usage when it remains wetted with new batches of MMA resin, but will need to be replaced when it starts ‘pulling’ material or creating differences in texture. Stopping and starting will decrease the useful life of the roller.

As material gels, but before it cures, remove masking.

**Clean up:** Clean all tooling in acetone before material is cured. Clean in well ventilated areas to reduce fume build-up and worker exposure. Do not come into direct contact with solvents - use proper personal protective equipment. Acetone is extremely flammable; take proper handling measures to reduce static discharge and combustion. Dispose of all contaminated materials in accordance with all applicable federal, state and local laws and regulations.

**Opening to traffic:** MMAX AREA MARKINGS must be 100% cured, which will be a hardened solid state, before traffic is permitted. Curing is based on temperatures and amount of catalyst added, but typically takes 30-60 minutes.