

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-TJB0-F31	50C Multi TECK90 / AWG 14	Tray	TJB-F31	TJB0-F31	Control	Addendum 11
A-TJB0-F31	4x Pair TECK90 / AWG 16	Tray	TJB-F31	TJB0-F31	Control	Addendum 11
C-TJB0-F32	50C Multi TECK90 / AWG 14	Tray	TJB-F31	TJB0-F32	Control	Addendum 11
A-TJB0-F32	4x Pair TECK90 / AWG 16	Tray	TJB-F31	TJB0-F32	Control	Addendum 11
C-TJB0-F33	50C Multi TECK90 / AWG 14	Tray	TJB-F32	TJB0-F33	Control	Addendum 11
A-TJB0-F33	4x Pair TECK90 / AWG 16	Tray	TJB-F32	TJB0-F33	Control	Addendum 11
C-TJB0-F34	50C Multi TECK90 / AWG 14	Tray	TJB-F32	TJB0-F34	Control	Addendum 11
A-TJB0-F34	4x Pair TECK90 / AWG 16	Tray	TJB-F32	TJB0-F34	Control	Addendum 11
C-TJB-A11	50C Multi TECK90 / AWG 14	Tray	CP-H10	TJB-A11	Control	Addendum 11
C-TJB-A11	50C Multi TECK90 / AWG 14	Tray	CP-H10	TJB-A11	Control	Addendum 11
C-TJB-A11	50C Multi TECK90 / AWG 14	Tray	CP-H10	TJB-A11	Control	Addendum 11
A-TJB-A11	50x Pair TECK90 / AWG 16	Tray	CP-H10	TJB-A11	Control	Addendum 11
C-TJB-C11	80C Multi TECK90 / AWG 14	Tray	CP-H30	TJB-C11	Control	Addendum 11
A-TJB-C11	12x Pair TECK90 / AWG 16	Tray	CP-H30	TJB-C11	Control	Addendum 11
C-TJB-C12	50C Multi TECK90 / AWG 14	Tray	CP-H30	TJB-C12	Control	Addendum 11
C-TJB-C12	50C Multi TECK90 / AWG 14	Tray	CP-H30	TJB-C12	Control	Addendum 11
A-TJB-C12	12x Pair TECK90 / AWG 16	Tray	CP-H30	TJB-C12	Control	Addendum 11
C-TJB-C13	50C Multi TECK90 / AWG 14	Tray	CP-C11	TJB-C13	Control	Addendum 11
A-TJB-C13	8x Pair TECK90 / AWG 16	Tray	CP-C11	TJB-C13	Control	Addendum 11
A-TJB-I31A	24x Pair TECK90 / AWG 16	Tray	CP-H10	TJB-I31A	Control	Addendum 11
C-TJB-I31B	80C Multi TECK90 / AWG 14	Tray	CP-H10	TJB-I31B	Control	Addendum 11
C-TJB-F31	50C Multi TECK90 / AWG 14	Tray	CP-H30	TJB-F31	Control	Addendum 11
A-TJB-F31	8x Pair TECK90 / AWG 16	Tray	CP-H30	TJB-F31	Control	Addendum 11
C-TJB-F32	60C Multi TECK90 / AWG 14	Tray	CP-H30	TJB-F32	Control	Addendum 11
A-TJB-F32	8x Pair TECK90 / AWG 16	Tray	CP-H30	TJB-F32	Control	Addendum 11
C-TJB-P13	80C Multi TECK90 / AWG 14	Tray	CP-P31	TJB-P13	Control	Addendum 11
A-TJB-P13	16x Pair TECK90 / AWG 16	Tray	CP-P31	TJB-P13	Control	Addendum 11
C-TJB-P14	30C Multi TECK90 / AWG 14	Tray	CP-P32	TJB-P14	Control	Addendum 11
A-TJB-P14	16x Pair TECK90 / AWG 16	Tray	CP-P32	TJB-P14	Control	Addendum 11
C-TJB-P33	50C Multi TECK90 / AWG 14	Tray	CP-P31	TJB-P33	Control	Addendum 11
C-TJB-P33	50C Multi TECK90 / AWG 14	Tray	CP-P31	TJB-P33	Control	Addendum 11
A-TJB-P33	24x Pair TECK90 / AWG 16	Tray	CP-P31	TJB-P33	Control	Addendum 11
C-TJB-P34	50C Multi TECK90 / AWG 14	Tray	CP-P32	TJB-P34	Control	Addendum 11
C-TJB-P34	50C Multi TECK90 / AWG 14	Tray	CP-P32	TJB-P34	Control	Addendum 11
A-TJB-P34	30x Pair TECK90 / AWG 16	Tray	CP-P32	TJB-P34	Control	Addendum 11
C-LT-I000A	4C Multi TECK90 / AWG 14	Tray	JB-I31B	LT-I000A	Control	
A-LT-I000A	1x Pair TECK90 / AWG 16	Tray	JB-I31A	LT-I000A	Control	
C-LS-I000A	2C Multi TECK90 / AWG 14	Tray	JB-I31B	LS-I000A	Control	
C-LS-I000C	2C Multi TECK90 / AWG 14	Tray	JB-I31B	LS-I000C	Control	
C-HV-I001C	4C Multi TECK90 / AWG 14	Tray	JB-I31B	HV-I001C	Control	
C-HV-I002C	4C Multi TECK90 / AWG 14	Tray	JB-I31B	HV-I002C	Control	
C-SLG-I000C	10C Multi TECK90 / AWG 14	Tray	JB-I31B	SLG-I000C	Control	
C-FV-I000A	7C Multi TECK90 / AWG 14	Tray	JB-I31B	FV-I000A	Control	
C-HV-I005A	2C Multi TECK90 / AWG 14	Tray	JB-I31B	HV-I005A	Control	
C-LT-I000B	4C Multi TECK90 / AWG 14	Tray	JB-I31B	LT-I000B	Control	
A-LT-I000B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	LT-I000B	Control	
C-LS-I000B	2C Multi TECK90 / AWG 14	Tray	JB-I31B	LS-I000B	Control	
C-LS-I000D	2C Multi TECK90 / AWG 14	Tray	JB-I31B	LS-I000D	Control	
C-FV-I000B	7C Multi TECK90 / AWG 14	Tray	JB-I31B	FV-I000B	Control	
C-HV-I003C	4C Multi TECK90 / AWG 14	Tray	JB-I31B	HV-I003C	Control	
C-HV-I004C	4C Multi TECK90 / AWG 14	Tray	JB-I31B	HV-I004C	Control	
C-HV-I005B	2C Multi TECK90 / AWG 14	Tray	JB-I31B	HV-I005B	Control	
A-VT-I001A	1x Pair TECK90 / AWG 16	Tray	LCP-I001A	VT-I001A	Control	
A-TE-I001x	9x Triad TECK90 / AWG 16	Tray	LCP-I001A	TE-I001x	Control	
A-TT-I001x	2x Pair TECK90 / AWG 16	Tray	LCP-I001A	TT-I001x	Control	Addendum 3
C-HS-I001A	3C Multi TECK90 / AWG 14	Tray	LCP-I001A	HS-I001A	Control	
A-ZT-I001B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZT-I001B	Control	
A-ZC-I001B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZC-I001B	Control	
C-HS-I001B	2C Multi TECK90 / AWG 14	Tray	JB-I31B	HS-I001B	Control	
C-LCP-I001A	6C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-I001A	Control	
A-ST-I001A	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ST-I001A	Control	Addendum 11
A-VT-I002A	1x Pair TECK90 / AWG 16	Tray	LCP-I002A	VT-I002A	Control	
A-TE-I002x	9x Triad TECK90 / AWG 16	Tray	LCP-I002A	TE-I002x	Control	
A-TT-I002x	2x Pair TECK90 / AWG 16	Tray	LCP-I002A	TT-I002x	Control	Addendum 3
C-HS-I002A	3C Multi TECK90 / AWG 14	Tray	LCP-I002A	HS-I002A	Control	
A-ZT-I002B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZT-I002B	Control	
A-ZC-I002B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZC-I002B	Control	
C-HS-I002B	2C Multi TECK90 / AWG 14	Tray	JB-I31B	HS-I002B	Control	
C-LCP-I002A	6C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-I002A	Control	
A-ST-I002A	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ST-I002A	Control	Addendum 11
A-VT-I003A	1x Pair TECK90 / AWG 16	Tray	LCP-I003A	VT-I003A	Control	
A-TE-I003x	9x Triad TECK90 / AWG 16	Tray	LCP-I003A	TE-I003x	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
A-TT-I003x	2x Pair TECK90 / AWG 16	Tray	LCP-I003A	TT-I003x	Control	Addendum 3
C-HS-I003A	3C Multi TECK90 / AWG 14	Tray	LCP-I003A	HS-I003A	Control	
A-ZT-I003B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZT-I003B	Control	
A-ZC-I003B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZC-I003B	Control	
C-HS-I003B	2C Multi TECK90 / AWG 14	Tray	JB-I31B	HS-I003B	Control	
C-LCP-I003A	6C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-I003A	Control	
A-ST-I003A	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ST-I003A	Control	Addendum 11
A-TE-I004x	9x Triad TECK90 / AWG 16	Tray	LCP-I004A	TE-I004x	Control	
A-TT-I004x	2x Pair TECK90 / AWG 16	Tray	LCP-I004A	TT-I004x	Control	Addendum 3
C-HS-I004A	3C Multi TECK90 / AWG 14	Tray	LCP-I004A	HS-I004A	Control	
A-ZT-I004B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZT-I004B	Control	
A-ZC-I004B	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ZC-I004B	Control	
C-HS-I004B	2C Multi TECK90 / AWG 14	Tray	JB-I31B	HS-I004B	Control	
C-LCP-I004A	6C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-I004A	Control	
A-ST-I004A	1x Pair TECK90 / AWG 16	Tray	JB-I31A	ST-I004A	Control	Addendum 11
C-FV-F101A	7C Multi RW90 / AWG 14	Conduit	JB0-F31	FV-F101A	Control	
C-FV-F102A	7C Multi RW90 / AWG 14	Conduit	JB0-F31	FV-F102A	Control	
C-LT-F100A	4C Multi RW90 / AWG 14	Conduit	JB0-F31	LT-F100A	Control	
A-LT-F100A	1x Pair Beldon / AWG 16	Conduit	JB0-F31	LT-F100A	Control	
C-FV-F107A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F107A	Control	
A-PT-F100A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	PT-F100A	Control	
C-FV-F106A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F106A	Control	
C-FT-F103A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	FT-F103A	Control	
A-FT-F103A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FT-F103A	Control	
C-FCV-F103A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	FCV-F103A	Control	
A-FCV-F103A	2x Pair TECK90 / AWG 16	Tray	LCP-F01	FCV-F103A	Control	
C-FV-F104A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F104A	Control	
C-FV-F105A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F105A	Control	
C-AT-F110A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F110A	Control	
A-AT-F110A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F110A	Control	
C-FS-F110A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F110A	Control	
C-AT-F110B	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F110B	Control	
A-AT-F110B	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F110B	Control	
C-FS-F110B	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F110B	Control	
C-FV-F201A	7C Multi RW90 / AWG 14	Conduit	JB0-F31	FV-F201A	Control	
C-FV-F202A	7C Multi RW90 / AWG 14	Conduit	JB0-F31	FV-F202A	Control	
C-LT-F200A	4C Multi RW90 / AWG 14	Conduit	JB0-F31	LT-F200A	Control	
A-LT-F200A	1x Pair Beldon / AWG 16	Conduit	JB0-F31	LT-F200A	Control	
C-FV-F207A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F207A	Control	
A-PT-F200A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	PT-F200A	Control	
C-FV-F206A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F206A	Control	
C-FT-F203A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	FT-F203A	Control	
A-FT-F203A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FT-F203A	Control	
C-FCV-F203A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	FCV-F203A	Control	
A-FCV-F203A	2x Pair TECK90 / AWG 16	Tray	LCP-F01	FCV-F203A	Control	
C-FV-F204A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F204A	Control	
C-FV-F205A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F205A	Control	
C-AT-F210A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F210A	Control	
A-AT-F210A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F210A	Control	
C-FS-F210A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F210A	Control	
C-AT-F210B	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F210B	Control	
A-AT-F210B	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F210B	Control	
C-FS-F210B	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F210B	Control	
C-FV-F301A	7C Multi RW90 / AWG 14	Conduit	JB0-F32	FV-F301A	Control	
C-FV-F302A	7C Multi RW90 / AWG 14	Conduit	JB0-F32	FV-F302A	Control	
C-LT-F300A	4C Multi RW90 / AWG 14	Conduit	JB0-F32	LT-F300A	Control	
A-LT-F300A	1x Pair Beldon / AWG 16	Conduit	JB0-F32	LT-F300A	Control	
C-FV-F307A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F307A	Control	
A-PT-F300A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	PT-F300A	Control	
C-FV-F306A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F306A	Control	
C-FT-F303A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	FT-F303A	Control	
A-FT-F303A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FT-F303A	Control	
C-FCV-F303A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	FCV-F303A	Control	
A-FCV-F303A	2x Pair TECK90 / AWG 16	Tray	LCP-F01	FCV-F303A	Control	
C-FV-F304A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F304A	Control	
C-FV-F305A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F305A	Control	
C-AT-F310A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F310A	Control	
A-AT-F310A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F310A	Control	
C-FS-F310A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F310A	Control	
C-AT-F310B	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F310B	Control	
A-AT-F310B	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F310B	Control	
C-FS-F310B	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F310B	Control	
C-FV-F401A	7C Multi RW90 / AWG 14	Conduit	JB0-F32	FV-F401A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-FV-F402A	7C Multi RW90 / AWG 14	Conduit	JB0-F32	FV-F402A	Control	
C-LT-F400A	4C Multi RW90 / AWG 14	Conduit	JB0-F32	LT-F400A	Control	
A-LT-F400A	1x Pair Beldon / AWG 16	Conduit	JB0-F32	LT-F400A	Control	
C-FV-F407A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F407A	Control	
A-PT-F400A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	PT-F400A	Control	
C-FV-F406A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F406A	Control	
C-FT-F403A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	FT-F403A	Control	
A-FT-F403A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	FT-F403A	Control	
C-FCV-F403A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	FCV-F403A	Control	
A-FCV-F403A	2x Pair TECK90 / AWG 16	Tray	LCP-F01	FCV-F403A	Control	
C-FV-F404A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F404A	Control	
C-FV-F405A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F405A	Control	
C-AT-F410A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F410A	Control	
A-AT-F410A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F410A	Control	
C-FS-F410A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F410A	Control	
C-AT-F410B	6C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F410B	Control	
A-AT-F410B	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F410B	Control	
C-FS-F410B	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-F410B	Control	
C-FV-F501A	7C Multi RW90 / AWG 14	Conduit	JB0-F33	FV-F501A	Control	
C-FV-F502A	7C Multi RW90 / AWG 14	Conduit	JB0-F33	FV-F502A	Control	
C-LT-F500A	4C Multi RW90 / AWG 14	Conduit	JB0-F33	LT-F500A	Control	
A-LT-F500A	1x Pair Beldon / AWG 16	Conduit	JB0-F33	LT-F500A	Control	
C-FV-F507A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F507A	Control	
A-PT-F500A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	PT-F500A	Control	
C-FV-F506A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F506A	Control	
C-FT-F503A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	FT-F503A	Control	
A-FT-F503A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	FT-F503A	Control	
C-FCV-F503A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	FCV-F503A	Control	
A-FCV-F503A	2x Pair TECK90 / AWG 16	Tray	LCP-F02	FCV-F503A	Control	
C-FV-F504A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F504A	Control	
C-FV-F505A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F505A	Control	
C-AT-F510A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F510A	Control	
A-AT-F510A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F510A	Control	
C-FS-F510A	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F510A	Control	
C-AT-F510B	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F510B	Control	
A-AT-F510B	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F510B	Control	
C-FS-F510B	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F510B	Control	
C-FV-F601A	7C Multi RW90 / AWG 14	Conduit	JB0-F33	FV-F601A	Control	
C-FV-F602A	7C Multi RW90 / AWG 14	Conduit	JB0-F33	FV-F602A	Control	
C-LT-F600A	4C Multi RW90 / AWG 14	Conduit	JB0-F33	LT-F600A	Control	
A-LT-F600A	1x Pair Beldon / AWG 16	Conduit	JB0-F33	LT-F600A	Control	
C-FV-F607A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F607A	Control	
A-PT-F600A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	PT-F600A	Control	
C-FV-F606A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F606A	Control	
C-FT-F603A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	FT-F603A	Control	
A-FT-F603A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	FT-F603A	Control	
C-FCV-F603A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	FCV-F603A	Control	
A-FCV-F603A	2x Pair TECK90 / AWG 16	Tray	LCP-F02	FCV-F603A	Control	
C-FV-F604A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F604A	Control	
C-FV-F605A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F605A	Control	
C-AT-F610A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F610A	Control	
A-AT-F610A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F610A	Control	
C-FS-F610A	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F610A	Control	
C-AT-F610B	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F610B	Control	
A-AT-F610B	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F610B	Control	
C-FS-F610B	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F610B	Control	
C-FV-F701A	7C Multi RW90 / AWG 14	Conduit	JB0-F34	FV-F701A	Control	
C-FV-F702A	7C Multi RW90 / AWG 14	Conduit	JB0-F34	FV-F702A	Control	
C-LT-F700A	4C Multi RW90 / AWG 14	Conduit	JB0-F34	LT-F700A	Control	Addendum 11
A-LT-F700A	1x Pair Beldon / AWG 16	Conduit	JB0-F34	LT-F700A	Control	
C-FV-F707A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F707A	Control	
A-PT-F700A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	PT-F700A	Control	
C-FV-F706A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F706A	Control	
C-FT-F703A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	FT-F703A	Control	
A-FT-F703A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	FT-F703A	Control	
C-FCV-F703A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	FCV-F703A	Control	
A-FCV-F703A	2x Pair TECK90 / AWG 16	Tray	LCP-F02	FCV-F703A	Control	
C-FV-F704A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F704A	Control	
C-FV-F705A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F705A	Control	
C-AT-F710A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F710A	Control	
A-AT-F710A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F710A	Control	
C-FS-F710A	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F710A	Control	
C-AT-F710B	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F710B	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
A-AT-F710B	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F710B	Control	
C-FS-F710B	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F710B	Control	
C-FV-F801A	7C Multi RW90 / AWG 14	Conduit	JB0-F34	FV-F801A	Control	
C-FV-F802A	7C Multi RW90 / AWG 14	Conduit	JB0-F34	FV-F802A	Control	
C-LT-F800A	4C Multi RW90 / AWG 14	Conduit	JB0-F34	LT-F800A	Control	
A-LT-F800A	1x Pair Beldon / AWG 16	Conduit	JB0-F34	LT-F800A	Control	
C-FV-F807A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F807A	Control	
A-PT-F800A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	PT-F800A	Control	
C-FV-F806A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F806A	Control	
C-FT-F803A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	FT-F803A	Control	
A-FT-F803A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	FT-F803A	Control	
C-FCV-F803A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	FCV-F803A	Control	
A-FCV-F803A	2x Pair TECK90 / AWG 16	Tray	LCP-F02	FCV-F803A	Control	
C-FV-F804A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F804A	Control	
C-FV-F805A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F805A	Control	
C-AT-F810A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F810A	Control	
A-AT-F810A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F810A	Control	
C-FS-F810A	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F810A	Control	
C-AT-F810B	6C Multi TECK90 / AWG 14	Tray	LCP-F02	AT-F810B	Control	
A-AT-F810B	1x Pair TECK90 / AWG 16	Tray	LCP-F02	AT-F810B	Control	
C-FS-F810B	2C Multi TECK90 / AWG 14	Tray	LCP-F02	FS-F810B	Control	
C-FV-J991A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-J991A	Control	
A-PT-F910A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	PT-F910A	Control	
C-FV-F912A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F912A	Control	
C-FV-F910A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F910A	Control	
C-FCV-F911A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	FCV-F911A	Control	
A-FCV-F911A	2x Pair TECK90 / AWG 16	Tray	LCP-F01	FCV-F911A	Control	
A-TT-F911A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	TT-F911A	Control	
C-PS-F911A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	PS-F911A	Control	
A-PT-F911A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	PT-F911A	Control	
C-FT-F911A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	FT-F911A	Control	
A-FT-F911A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FT-F911A	Control	
C-FV-F931A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F931A	Control	
C-HS-F931A	5C Multi TECK90 / AWG 14	Tray	FV-F931A	HS-F931A	Control	
A-PT-F920A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	PT-F920A	Control	
C-FV-F922A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F922A	Control	
C-FV-F920A	7C Multi TECK90 / AWG 14	Tray	LCP-F02	FV-F920A	Control	
C-FV-F932A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F932A	Control	
C-FCV-F921A	6C Multi TECK90 / AWG 14	Tray	LCP-F02	FCV-F921A	Control	
A-FCV-F921A	2x Pair TECK90 / AWG 16	Tray	LCP-F02	FCV-F921A	Control	
A-TT-F921A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	TT-F921A	Control	
A-PT-F921A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	PT-F921A	Control	
C-FT-F921A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	FT-F921A	Control	
A-FT-F921A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	FT-F921A	Control	
C-FV-F933A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F933A	Control	
C-FV-J992A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-J992A	Control	
A-PT-F010A	1x Pair TECK90 / AWG 16	Tray	CP-H30	PT-F010A	Control	
C-VS-F010A	2C Multi TECK90 / AWG 14	Tray	MCC4A	VS-F010A	Control	
C-IS-F010A	2C Multi TECK90 / AWG 14	Tray	MCC4A	IS-F010A	Control	
C-HS-F010A	3C Multi TECK90 / AWG 14	Tray	LCP-F010B	HS-F010A	Control	
C-LCP-F010B	8C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-F010B	Control	
A-LCP-F010B	1x Pair TECK90 / AWG 16	Tray	CP-H30	LCP-F010B	Control	
A-TT-F010x	8x Triad TECK90 / AWG 16	Tray	MCC4A	TT-F010x	Control	
A-PT-F010B	1x Pair TECK90 / AWG 16	Tray	CP-H30	PT-F010B	Control	
C-FV-F010A	7C Multi TECK90 / AWG 14	Tray	CP-H30	FV-F010A	Control	
A-PT-F020A	1x Pair TECK90 / AWG 16	Tray	CP-H30	PT-F020A	Control	
C-VS-F020A	2C Multi TECK90 / AWG 14	Tray	MCC4B	VS-F020A	Control	
C-IS-F020A	2C Multi TECK90 / AWG 14	Tray	MCC4B	IS-F020A	Control	
C-HS-F020A	3C Multi TECK90 / AWG 14	Tray	LCP-F020B	HS-F020A	Control	
C-LCP-F020B	8C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-F020B	Control	
A-LCP-F020B	1x Pair TECK90 / AWG 16	Tray	CP-H30	LCP-F020B	Control	
A-TT-F020x	8x Triad TECK90 / AWG 16	Tray	MCC4B	TT-F020x	Control	
A-PT-F020B	1x Pair TECK90 / AWG 16	Tray	CP-H30	PT-F020B	Control	
C-FV-F020A	7C Multi TECK90 / AWG 14	Tray	CP-H30	FV-F020A	Control	
A-TT-F030A	1x Pair TECK90 / AWG 16	Tray	CP-H30	TT-F030A	Control	
C-FT-F030A	4C Multi TECK90 / AWG 14	Tray	CP-H30	FT-F030A	Control	
A-FT-F030A	1x Pair TECK90 / AWG 16	Tray	CP-H30	FT-F030A	Control	
C-FV-F052A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F052A	Control	
C-FV-F051A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-F051A	Control	
C-LT-F050A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-F050A	Control	
A-LT-F050A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-F050A	Control	
C-SLG-F053A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-F053A	Control	
C-SLG-F054A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-F054A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-SLG-F055A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-F055A	Control	
A-FS-F056A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FS-F056A	Control	
C-AT-F056A	7C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-F056A	Control	
A-AT-F056A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-F056A	Control	
C-LCP-F055A	10C Multi TECK90 / AWG 14	Tray	LCP-F01	LCP-F055A	Control	
C-FS-F055A	2C Multi TECK90 / AWG 14	Tray	LCP-F055A	FS-F055A	Control	
C-LT-F980A	4C Multi TECK90 / AWG 14	Tray	LCP-F02	LT-F980A	Control	
A-LT-F980A	1x Pair TECK90 / AWG 16	Tray	LCP-F02	LT-F980A	Control	
C-LT-F980B	4C Multi TECK90 / AWG 14	Tray	LCP-F02	LT-F980B	Control	
A-LT-F980B	1x Pair TECK90 / AWG 16	Tray	LCP-F02	LT-F980B	Control	
C-LY-F980B	2C Multi TECK90 / AWG 14	Tray	LCP-F981A	LY-F980B	Control	
C1-LY-F980B	2C Multi TECK90 / AWG 14	Tray	LCP-F983A	LY-F980B	Control	
C-AE-F981A	2C Multi TECK90 / AWG 14	Tray	LCP-F981A	AE-F981A	Control	
C-AE-F982A	2C Multi TECK90 / AWG 14	Tray	LCP-F981A	AE-F982A	Control	
C-LCP-F981A	16C Multi TECK90 / AWG 14	Tray	LCP-F02	LCP-F981A	Control	
C-AE-F983A	2C Multi TECK90 / AWG 14	Tray	LCP-F983A	AE-F983A	Control	
C-LCP-F983A	8C Multi TECK90 / AWG 14	Tray	LCP-F02	LCP-F983A	Control	
C-AE-F984A	2C Multi TECK90 / AWG 14	Tray	LCP-F984A	AE-F984A	Control	
C-LCP-F984A	12C Multi TECK90 / AWG 14	Tray	LCP-F02	LCP-F984A	Control	
C-LS-F984A	2C Multi TECK90 / AWG 14	Tray	LCP-F02	LS-F984A	Control	
C-LS-F984B	2C Multi TECK90 / AWG 14	Tray	LCP-F02	LS-F984B	Control	
C-HS-F911A	3C Multi TECK90 / AWG 14	Tray	LCP-F911A	HS-F911A	Control	
A-TE-F911x	8x Pair TECK90 / AWG 16	Tray	LCP-F911A	TE-F911x	Control	
C-LCP-F911A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-F911A	Control	
C-PS-F921A	2C Multi TECK90 / AWG 14	Tray	LCP-F921A	PS-F921A	Control	
C-HS-F921A	3C Multi TECK90 / AWG 14	Tray	LCP-F921A	HS-F921A	Control	
A-TE-F921A	8x Pair TECK90 / AWG 16	Tray	LCP-F921A	TE-F921A	Control	
C-LCP-F921A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-F921A	Control	
C-LCP-J702A	8C Multi TECK90 / AWG 14	Tray	LCP-F01	LCP-J702A	Control	
C-PS-J702A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	PS-J702A	Control	
C-FV-J702C	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-J702C	Control	
C-FT-J702A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	FT-J702A	Control	
A-FT-J702A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FT-J702A	Control	
C-FS-C110B	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-C110B	Control	Addendum 3
C-FV-J703C	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-J703C	Control	
C-LCP-J701A	8C Multi TECK90 / AWG 14	Tray	LCP-F01	LCP-J701A	Control	
C-PS-J701A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	PS-J701A	Control	
C-FV-J701C	7C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-J701C	Control	
C-FT-J701A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	FT-J701A	Control	
A-FT-J701A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	FT-J701A	Control	
C-FS-C110A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-C110A	Control	Addendum 3
C-FV-C110B	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-C110B	Control	
C-FV-C110A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FV-C110A	Control	
C-YS-C800A	2C Multi TECK90 / AWG 14	Tray	LCP-C800A	YS-C800A	Control	Addendum 11
C-LA-C800A	2C Multi TECK90 / AWG 14	Tray	LCP-C800A	LA-C800A	Control	Addendum 11
C-LA-C800B	2C Multi TECK90 / AWG 14	Tray	LCP-C800A	LA-C800B	Control	Addendum 11
C-FV-C810B	7C Multi TECK90 / AWG 14	Tray	LCP-C800A	FV-C810B	Control	
C1-LT-C810A	4C Multi TECK90 / AWG 14	Tray	TJB-C12	LT-C810A	Control	
A1-LT-C810A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	LT-C810A	Control	
C2-LT-C810A	4C Multi TECK90 / AWG 14	Tray	LCP-C800A	LT-C810A	Control	
A2-LT-C810A	1x Pair TECK90 / AWG 16	Tray	LCP-C800A	LT-C810A	Control	
A-LE-C810A	1x Pair TECK90 / AWG 16	Tray	LT-C810A	LE-C810A	Control	
A-TT-C810A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	TT-C810A	Control	Addendum 3
C-HV-C830A	3C Multi TECK90 / AWG 14	Tray	TJB-C12	HV-C830A	Control	Addendum 3
C-FV-C820B	7C Multi TECK90 / AWG 14	Tray	TJB-C12	FV-C820B	Control	
C1-LT-C820A	4C Multi TECK90 / AWG 14	Tray	TJB-C12	LT-C820A	Control	
A1-LT-C820A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	LT-C820A	Control	
C2-LT-C820A	4C Multi TECK90 / AWG 14	Tray	LCP-C800A	LT-C820A	Control	
A2-LT-C820A	1x Pair TECK90 / AWG 16	Tray	LCP-C800A	LT-C820A	Control	
A-LE-C820A	1x Pair TECK90 / AWG 16	Tray	LT-C820A	LE-C820A	Control	
A-TT-C820A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	TT-C820A	Control	Addendum 3
C-HV-C830C	3C Multi TECK90 / AWG 14	Tray	TJB-C12	HV-C830C	Control	Addendum 3
C-LS-C800A	2C Multi TECK90 / AWG 14	Tray	TJB-C12	LS-C800A	Control	
C-FV-C840A	2C Multi TECK90 / AWG 14	Tray	TJB-C12	FV-C840A	Control	
C-FS-C840A	2C Multi TECK90 / AWG 14	Tray	TJB-C12	FS-C840A	Control	
A-FT-C840A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	FT-C840A	Control	
C-FV-C850A	10C Multi TECK90 / AWG 14	Tray	TJB-C12	FV-C850A	Control	
C-FS-C850A	2C Multi TECK90 / AWG 14	Tray	TJB-C12	FS-C850A	Control	
A-FT-C850A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	FT-C850A	Control	
C-FV-C860A	2C Multi TECK90 / AWG 14	Tray	TJB-C12	FV-C860A	Control	
C-FS-C860A	2C Multi TECK90 / AWG 14	Tray	TJB-C12	FS-C860A	Control	
A-FT-C860A	1x Pair TECK90 / AWG 16	Tray	TJB-C12	FT-C860A	Control	
C-FV-C860C	7C Multi TECK90 / AWG 14	Tray	TJB-C12	FV-C860C	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-FV-C860D	7C Multi TECK90 / AWG 14	Tray	TJB-C12	FV-C860D	Control	
C-FV-C940J	7C Multi TECK90 / AWG 14	Tray	TJB-C11	FV-C940J	Control	Addendum 11
C-LT-C940B	4C Multi TECK90 / AWG 14	Tray	TJB-C11	LT-C940B	Control	Addendum 11
A-LE-C940B	1x Pair TECK90 / AWG 16	Tray	LT-C940B	LE-C940B	Control	
C-LS-C980A	2C Multi TECK90 / AWG 14	Tray	TJB-C11	LS-C980A	Control	
A-FT-C950A	1x Pair TECK90 / AWG 16	Tray	TJB-C11	FT-C950A	Control	
C-FV-C950A	2C Multi TECK90 / AWG 14	Tray	TJB-C11	FV-C950A	Control	
C-FS-C950A	2C Multi TECK90 / AWG 14	Tray	TJB-C11	FS-C950A	Control	
A-FT-C960A	1x Pair TECK90 / AWG 16	Tray	TJB-C11	FT-C960A	Control	
C-FV-C960A	2C Multi TECK90 / AWG 14	Tray	TJB-C11	FV-C960A	Control	
C-FS-C960A	2C Multi TECK90 / AWG 14	Tray	TJB-C11	FS-C960A	Control	
A-FT-C970A	1x Pair TECK90 / AWG 16	Tray	TJB-C11	FT-C970A	Control	
C-FV-C970A	7C Multi TECK90 / AWG 14	Tray	TJB-C11	FV-C970A	Control	
C-FS-C970A	2C Multi TECK90 / AWG 14	Tray	TJB-C11	FS-C970A	Control	
C-FV-C970D	7C Multi TECK90 / AWG 14	Tray	TJB-C11	FV-C970D	Control	
C-FV-C970C	7C Multi TECK90 / AWG 14	Tray	TJB-C11	FV-C970C	Control	
C-HS-C020A	3C Multi TECK90 / AWG 14	Tray	PCU-C020	HS-C020A	Control	
C-PCU-C020	8C Multi TECK90 / AWG 14	Tray	TJB-C13	PCU-C020	Control	Addendum 11
C-LS-C020A	2C Multi TECK90 / AWG 14	Tray	TJB-C13	LS-C020A	Control	Addendum 11
C-LS-C020B	2C Multi TECK90 / AWG 14	Tray	TJB-C13	LS-C020B	Control	Addendum 11
C-WT-C020A	4C Multi TECK90 / AWG 14	Tray	TJB-C13	WT-C020A	Control	Addendum 11
A-WT-C020A	1x Pair TECK90 / AWG 16	Tray	TJB-C13	WT-C020A	Control	Addendum 11
C-HS-C020B	3C Multi TECK90 / AWG 14	Tray	PCU-C020	HS-C020B	Control	
C-CFR-C020B	4C Multi TECK90 / AWG 14	Tray	TJB-C13	CFR-C020B	Control	Addendum 11
C-HS-C030A	3C Multi TECK90 / AWG 14	Tray	PCU-C030	HS-C030A	Control	
C-LS-C030A	2C Multi TECK90 / AWG 14	Tray	TJB-C13	LS-C030A	Control	Addendum 11
C-LS-C030B	2C Multi TECK90 / AWG 14	Tray	TJB-C13	LS-C030B	Control	Addendum 11
C-WT-C030A	4C Multi TECK90 / AWG 14	Tray	TJB-C13	WT-C030A	Control	Addendum 11
A-WT-C030A	1x Pair TECK90 / AWG 16	Tray	TJB-C13	WT-C030A	Control	Addendum 11
C-HS-C030B	3C Multi TECK90 / AWG 14	Tray	PCU-C030	HS-C030B	Control	
C-PCU-C030	8C Multi TECK90 / AWG 14	Tray	TJB-C13	PCU-C030	Control	Addendum 11
C-TS-C020A	8C Multi TECK90 / AWG 14	Tray	TJB-A11	TS-C020A	Control	
C-HS-C021A	3C Multi TECK90 / AWG 14	Tray	PPU-C021	HS-C021A	Control	
C-PPU-C021	15C Multi TECK90 / AWG 14	Tray	CP-C11	PPU-C021	Control	
C-SOL-C021B	2C Multi TECK90 / AWG 14	Tray	PPU-C021	SOL-C021B	Control	
C-LS-C021A	4C Multi TECK90 / AWG 14	Tray	PPU-C021	LS-C021A	Control	
C-FV-C021A	7C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C021A	Control	
C-HS-C031B	3C Multi TECK90 / AWG 14	Tray	PPU-C031	HS-C031B	Control	
C-PPU-C031	15C Multi TECK90 / AWG 14	Tray	CP-C11	PPU-C031	Control	
C-SOL-C031B	2C Multi TECK90 / AWG 14	Tray	PPU-C031	SOL-C031B	Control	
C-LS-C031A	4C Multi TECK90 / AWG 14	Tray	PPU-C031	LS-C031A	Control	
C-FV-C031A	7C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C031A	Control	
C-HS-C001A	3C Multi TECK90 / AWG 14	Tray	LCP-C001	HS-C001A	Control	
C-PPU-C001	8C Multi TECK90 / AWG 14	Tray	CP-C11	PPU-C001	Control	
C-FT-C001B	4C Multi TECK90 / AWG 14	Tray	LCP-C001	FT-C001B	Control	
A-FT-C001B	1x Pair TECK90 / AWG 16	Tray	CP-C11	FT-C001B	Control	
C-WT-C001B	2C Multi TECK90 / AWG 14	Tray	CP-C11	WT-C001B	Control	
A-WT-C001B	1x Pair TECK90 / AWG 16	Tray	CP-C11	WT-C001B	Control	
C-LS-C005A	2C Multi TECK90 / AWG 14	Tray	CP-C11	LS-C005A	Control	
C-LT-C022A	4C Multi TECK90 / AWG 14	Tray	CP-C11	LT-C022A	Control	
A-LE-C022A	1x Pair TECK90 / AWG 16	Tray	LT-C022A	LE-C022A	Control	
A-LT-C022A	1x Pair TECK90 / AWG 16	Tray	CP-C11	LT-C022A	Control	
C-LT-C032A	4C Multi TECK90 / AWG 14	Tray	CP-C11	LT-C032A	Control	
A-LE-C032A	1x Pair TECK90 / AWG 16	Tray	LT-C032A	LE-C032A	Control	
A-LT-C032A	1x Pair TECK90 / AWG 16	Tray	CP-C11	LT-C032A	Control	
C-TS-C061A	2C Multi TECK90 / AWG 14	Tray	LCP-C061A	TS-C061A	Control	
C-PS-C061A	2C Multi TECK90 / AWG 14	Tray	LCP-C061A	PS-C061A	Control	
C-FT-C061A	4C Multi TECK90 / AWG 14	Tray	CP-C11	FT-C061A	Control	
A-FT-C061A	1x Pair TECK90 / AWG 16	Tray	CP-C11	FT-C061A	Control	
C-FV-C061A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C061A	Control	
C-FS-C061A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FS-C061A	Control	
C-TS-C062A	2C Multi TECK90 / AWG 14	Tray	LCP-C062A	TS-C062A	Control	
C-PS-C062A	2C Multi TECK90 / AWG 14	Tray	LCP-C062A	PS-C062A	Control	
C-FT-C062A	4C Multi TECK90 / AWG 14	Tray	CP-C11	FT-C062A	Control	
A-FT-C062A	1x Pair TECK90 / AWG 16	Tray	CP-C11	FT-C062A	Control	
C-FV-C062A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C062A	Control	
C-FS-C062A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FS-C062A	Control	
C-TS-C063A	2C Multi TECK90 / AWG 14	Tray	LCP-C063A	TS-C063A	Control	
C-PS-C063A	2C Multi TECK90 / AWG 14	Tray	LCP-C063A	PS-C063A	Control	
C-FT-C063A	4C Multi TECK90 / AWG 14	Tray	CP-C11	FT-C063A	Control	
A-FT-C063A	1x Pair TECK90 / AWG 16	Tray	CP-C11	FT-C063A	Control	
C-FV-C063A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C063A	Control	
C-FS-C063A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FS-C063A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-FV-C064B	7C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C064B	Control	
C-FV-C065B	7C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C065B	Control	
C-TS-C071A	2C Multi TECK90 / AWG 14	Tray	LCP-C071A	TS-C071A	Control	
C-PS-C071A	2C Multi TECK90 / AWG 14	Tray	LCP-C071A	PS-C071A	Control	Addendum 3
C-FT-C071A	4C Multi TECK90 / AWG 14	Tray	CP-C11	FT-C071A	Control	
A-FT-C071A	1x Pair TECK90 / AWG 16	Tray	CP-C11	FT-C071A	Control	
C-FV-C071A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C071A	Control	
C-FS-C071A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FS-C071A	Control	
C-FV-C073A	7C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C073A	Control	
C-TS-C072A	2C Multi TECK90 / AWG 14	Tray	LCP-C072A	TS-C072A	Control	
C-PS-C072A	2C Multi TECK90 / AWG 14	Tray	LCP-C072A	PS-C072A	Control	
C-FT-C072A	4C Multi TECK90 / AWG 14	Tray	CP-C11	FT-C072A	Control	
A-FT-C072A	1x Pair TECK90 / AWG 16	Tray	CP-C11	FT-C072A	Control	
C-FV-C072A	7C Multi TECK90 / AWG 14	Tray	CP-C11	FV-C072A	Control	
C-FS-C072A	2C Multi TECK90 / AWG 14	Tray	CP-C11	FS-C072A	Control	
C-HS-O210	3C Multi TECK90 / AWG 14	Tray	TJB-F31	HS-O210	Control	
C-HS-O230	3C Multi TECK90 / AWG 14	Tray	TJB-F32	HS-O230	Control	
A-PT-O030A	1x Pair TECK90 / AWG 16	Tray	CP-O30	PT-O030A	Control	
A-PT-O031A	1x Pair TECK90 / AWG 16	Tray	CP-O30	PT-O031A	Control	
A-AT-O032A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O032A	Control	
C-CMP-O052A	2C Multi TECK90 / AWG 14	Tray	LCP-O050	CMP-O052A	Control	
C-CMP-O053A	2C Multi TECK90 / AWG 14	Tray	LCP-O050	CMP-O053A	Control	
C-FS-O051A	2C Multi TECK90 / AWG 14	Tray	CP-O30	FS-O051A	Control	
A-AT-O051A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O051A	Control	
C-FV-O119A	10C Multi TECK90 / AWG 14	Tray	PSU-O310A	FV-O119A	Control	
A-PT-O110A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	PT-O110A	Control	
A-TT-O110A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	TT-O110A	Control	
A-FM-O115A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	FM-O115A	Control	
C-LS-O110A	2C Multi TECK90 / AWG 14	Tray	PSU-O310A	LS-O110A	Control	
C-LS-O110B	2C Multi TECK90 / AWG 14	Tray	PSU-O310A	LS-O110B	Control	
A-PT-O112A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	PT-O112A	Control	
A-TT-O112A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	TT-O112A	Control	
A-FT-O112A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	FT-O112A	Control	
C-FCV-O112A	6C Multi TECK90 / AWG 14	Tray	PSU-O310A	FCV-O112A	Control	
A-FCV-O112A	2x Pair TECK90 / AWG 16	Tray	PSU-O310A	FCV-O112A	Control	
C-AT-O112A	4C Multi TECK90 / AWG 14	Tray	PSU-O310A	AT-O112A	Control	
A-AT-O112A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	AT-O112A	Control	
C-FV-O112B	10C Multi TECK90 / AWG 14	Tray	PSU-O310A	FV-O112B	Control	
C-AY-O110A	4C Multi TECK90 / AWG 14	Tray	LCP-O110A	AY-O110A	Control	Addendum 11
A-AT-O110A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O110A	Control	
C-AY-O110B	4C Multi TECK90 / AWG 14	Tray	CP-O30	AY-O110B	Control	Addendum 11
C-FV-O139A	10C Multi TECK90 / AWG 14	Tray	PSU-O320A	FV-O139A	Control	
A-PT-O130A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	PT-O130A	Control	
A-TT-O130A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	TT-O130A	Control	
C-LS-O130A	2C Multi TECK90 / AWG 14	Tray	PSU-O320A	LS-O130A	Control	
C-LS-O130B	2C Multi TECK90 / AWG 14	Tray	PSU-O320A	LS-O130B	Control	
A-PT-O132A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	PT-O132A	Control	
A-TT-O132A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	TT-O132A	Control	
A-FT-O132A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	FT-O132A	Control	
C-FCV-O132A	6C Multi TECK90 / AWG 14	Tray	PSU-O320A	FCV-O132A	Control	
A-FCV-O132A	2x Pair TECK90 / AWG 16	Tray	PSU-O320A	FCV-O132A	Control	
C-AT-O132A	4C Multi TECK90 / AWG 14	Tray	PSU-O320A	AT-O132A	Control	
A-AT-O132A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	AT-O132A	Control	
C-FV-O132B	10C Multi TECK90 / AWG 14	Tray	PSU-O320A	FV-O132B	Control	
C-AY-O130A	4C Multi TECK90 / AWG 14	Tray	LCP-O110A	AY-O130A	Control	Addendum 11
A-AT-O130A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O130A	Control	
C-AY-O130B	4C Multi TECK90 / AWG 14	Tray	CP-O30	AY-O130B	Control	Addendum 11
C-LCP-H32	2C Multi TECK90 / AWG 14	Tray	LCP-O110A	LCP-H32	Control	Retagged, Addendum 13
C-LCP-H32	2C Multi TECK90 / AWG 14	Tray	LCP-O110A	LCP-H32	Control	Addendum 13
C-FV-O159A	10C Multi TECK90 / AWG 14	Tray	PSU-O330A	FV-O159A	Control	
A-PT-O150A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	PT-O150A	Control	
A-TT-O150A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	TT-O150A	Control	
A-FM-O155A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	FM-O155A	Control	
C-LS-O150A	2C Multi TECK90 / AWG 14	Tray	PSU-O330A	LS-O150A	Control	
C-LS-O150B	2C Multi TECK90 / AWG 14	Tray	PSU-O330A	LS-O150B	Control	
A-PT-O152A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	PT-O152A	Control	
A-TT-O152A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	TT-O152A	Control	
A-FT-O152A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	FT-O152A	Control	
C-FCV-O152A	6C Multi TECK90 / AWG 14	Tray	PSU-O330A	FCV-O152A	Control	
A-FCV-O152A	2x Pair TECK90 / AWG 16	Tray	PSU-O330A	FCV-O152A	Control	
C-AT-O152A	4C Multi TECK90 / AWG 14	Tray	PSU-O330A	AT-O152A	Control	
A-AT-O152A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	AT-O152A	Control	
C-FV-O152A	10C Multi TECK90 / AWG 14	Tray	PSU-O330A	FV-O152A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-AY-O150A	4C Multi TECK90 / AWG 14	Tray	LCP-O110A	AY-O150A	Control	Addendum 11
A-AT-O150A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O150A	Control	
C-AY-O150A	4C Multi TECK90 / AWG 14	Tray	CP-O30	AY-O150A	Control	Addendum 11
C-FV-O201A	10C Multi TECK90 / AWG 14	Tray	CP-O30	FV-O201A	Control	
C-FV-O202A	10C Multi TECK90 / AWG 14	Tray	CP-O30	FV-O202A	Control	
C-FT-O216A	4C Multi TECK90 / AWG 14	Tray	CP-O30	FT-O216A	Control	
A-FT-O216A	1x Pair TECK90 / AWG 16	Tray	CP-O30	FT-O216A	Control	
C-FCV-O216A	6C Multi TECK90 / AWG 14	Tray	CP-O30	FCV-O216A	Control	
A-FCV-O216A	2x Pair TECK90 / AWG 16	Tray	CP-O30	FCV-O216A	Control	
C-FT-O217A	4C Multi TECK90 / AWG 14	Tray	CP-O30	FT-O217A	Control	
A-FT-O217A	1x Pair TECK90 / AWG 16	Tray	CP-O30	FT-O217A	Control	
C-FCV-O217A	6C Multi TECK90 / AWG 14	Tray	CP-O30	FCV-O217A	Control	
A-FCV-O217A	2x Pair TECK90 / AWG 16	Tray	CP-O30	FCV-O217A	Control	
C-FT-O218A	4C Multi TECK90 / AWG 14	Tray	CP-O30	FT-O218A	Control	
A-FT-O218A	1x Pair TECK90 / AWG 16	Tray	CP-O30	FT-O218A	Control	
C-FCV-O218A	6C Multi TECK90 / AWG 14	Tray	CP-O30	FCV-O218A	Control	
A-FCV-O218A	2x Pair TECK90 / AWG 16	Tray	CP-O30	FCV-O218A	Control	
C-FT-O236A	4C Multi TECK90 / AWG 14	Tray	CP-O30	FT-O236A	Control	
A-FT-O236A	1x Pair TECK90 / AWG 16	Tray	CP-O30	FT-O236A	Control	
C-FCV-O236A	6C Multi TECK90 / AWG 14	Tray	CP-O30	FCV-O236A	Control	
A-FCV-O236A	2x Pair TECK90 / AWG 16	Tray	CP-O30	FCV-O236A	Control	
C-FT-O237A	4C Multi TECK90 / AWG 14	Tray	CP-O30	FT-O237A	Control	
A-FT-O237A	1x Pair TECK90 / AWG 16	Tray	CP-O30	FT-O237A	Control	
C-FCV-O237A	6C Multi TECK90 / AWG 14	Tray	CP-O30	FCV-O237A	Control	
A-FCV-O237A	2x Pair TECK90 / AWG 16	Tray	CP-O30	FCV-O237A	Control	
C-FT-O238A	4C Multi TECK90 / AWG 14	Tray	CP-O30	FT-O238A	Control	
A-FT-O238A	1x Pair TECK90 / AWG 16	Tray	CP-O30	FT-O238A	Control	
C-FCV-O238A	6C Multi TECK90 / AWG 14	Tray	CP-O30	FCV-O238A	Control	
A-FCV-O238A	2x Pair TECK90 / AWG 16	Tray	CP-O30	FCV-O238A	Control	
C-HS-O210A	7C Multi TECK90 / AWG 14	Tray	SLG-O210A	HS-O210A	Control	
C-SLG-O210A	10C Multi TECK90 / AWG 14	Tray	TJB-P33	SLG-O210A	Control	
C-HS-O210B	7C Multi TECK90 / AWG 14	Tray	SLG-O210B	HS-O210B	Control	
C-SLG-O210B	10C Multi TECK90 / AWG 14	Tray	TJB-F31	SLG-O210B	Control	
C-HS-O210C	7C Multi TECK90 / AWG 14	Tray	SLG-O210C	HS-O210C	Control	
C-SLG-O210C	10C Multi TECK90 / AWG 14	Tray	TJB-F31	SLG-O210C	Control	
C-HS-C701A	3C Multi TECK90 / AWG 14	Tray	MXR-C701A	HS-C701A	Control	
C-MCC4A	8C Multi TECK90 / AWG 14	Tray	CP-H30	MCC4A	Control	
C-LT-C701A	4C Multi TECK90 / AWG 14	Tray	TJB-F31	LT-C701A	Control	
A-LT-C701A	1x Pair TECK90 / AWG 16	Tray	TJB-F31	LT-C701A	Control	
C-HS-O230A	7C Multi TECK90 / AWG 14	Tray	SLG-O230A	HS-O230A	Control	
C-SLG-O230A	10C Multi TECK90 / AWG 14	Tray	TJB-F32	SLG-O230A	Control	
C-HS-O230B	7C Multi TECK90 / AWG 14	Tray	SLG-O230B	HS-O230B	Control	
C-SLG-O230B	10C Multi TECK90 / AWG 14	Tray	TJB-F32	SLG-O230B	Control	
C-HS-O230C	7C Multi TECK90 / AWG 14	Tray	SLG-O230C	HS-O230C	Control	
C-SLG-O230C	10C Multi TECK90 / AWG 14	Tray	TJB-F32	SLG-O230C	Control	
C-HS-C702A	7C Multi TECK90 / AWG 14	Tray	MXR-C702A	HS-C702A	Control	
C-MXR-C702A	8C Multi TECK90 / AWG 14	Tray	CP-H30	MXR-C702A	Control	
C-LT-C702A	4C Multi TECK90 / AWG 14	Tray	TJB-F32	LT-C702A	Control	
A-LT-C702A	1x Pair TECK90 / AWG 16	Tray	TJB-F32	LT-C702A	Control	
C-SLG-F001A	4C Multi TECK90 / AWG 14	Tray	TJB-F32	SLG-F001A	Control	Addendum 3
A-PT-O501A	1x Pair TECK90 / AWG 16	Tray	CP-O30	PT-O501A	Control	
A-PT-O501B	1x Pair TECK90 / AWG 16	Tray	CP-O30	PT-O501B	Control	
A-AT-O501A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O501A	Control	
C-FV-O521A	10C Multi TECK90 / AWG 14	Tray	CP-O30	FV-O521A	Control	
C-FCV-O510A	6C Multi TECK90 / AWG 14	Tray	LCP-O510A	FCV-O510A	Control	
A-FCV-O510A	2x Pair TECK90 / AWG 16	Tray	LCP-O510A	FCV-O510A	Control	
A-TT-O510A	1x Pair TECK90 / AWG 16	Tray	LCP-O510A	TT-O510A	Control	
C-HTR-O510A	4C Multi TECK90 / AWG 14	Tray	LCP-O510A	HTR-O510A	Control	
A-TT-O510B	1x Pair TECK90 / AWG 16	Tray	LCP-O510A	TT-O510B	Control	
C-CDU-O510A	4C Multi TECK90 / AWG 14	Tray	LCP-O510A	CDU-O510A	Control	
A-PT-O510A	1x Pair TECK90 / AWG 16	Tray	LCP-O510A	PT-O510A	Control	
A-TT-O510C	1x Pair TECK90 / AWG 16	Tray	LCP-O510A	TT-O510C	Control	
C-BLW-O510A	4C Multi TECK90 / AWG 14	Tray	LCP-O510A	BLW-O510A	Control	
A-AT-O510A	1x Pair TECK90 / AWG 16	Tray	LCP-O510A	AT-O510A	Control	
C-LCP-O510A	10C Multi TECK90 / AWG 14	Tray	CP-O30	LCP-O510A	Control	
C-FCV-O520A	6C Multi TECK90 / AWG 14	Tray	LCP-O520A	FCV-O520A	Control	
A-FCV-O520A	2x Pair TECK90 / AWG 16	Tray	LCP-O520A	FCV-O520A	Control	
A-TT-O520A	1x Pair TECK90 / AWG 16	Tray	LCP-O520A	TT-O520A	Control	
C-HTR-O520A	4C Multi TECK90 / AWG 14	Tray	LCP-O520A	HTR-O520A	Control	
A-TT-O520B	1x Pair TECK90 / AWG 16	Tray	LCP-O520A	TT-O520B	Control	
C-CDU-O520A	4C Multi TECK90 / AWG 14	Tray	LCP-O520A	CDU-O520A	Control	
A-PT-O520A	1x Pair TECK90 / AWG 16	Tray	LCP-O520A	PT-O520A	Control	
A-TT-O520C	1x Pair TECK90 / AWG 16	Tray	LCP-O520A	TT-O520C	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-BLW-O520A	4C Multi TECK90 / AWG 14	Tray	LCP-O520A	BLW-O520A	Control	
A-PT-O520B	1x Pair TECK90 / AWG 16	Tray	LCP-O520A	PT-O520B	Control	
A-AT-O520A	1x Pair TECK90 / AWG 16	Tray	LCP-O520A	AT-O520A	Control	
C-LCP-O520A	10C Multi TECK90 / AWG 14	Tray	CP-O30	LCP-O520A	Control	
A-AT-O520B	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O520B	Control	
A-PT-O505A	1x Pair TECK90 / AWG 16	Tray	CP-O30	PT-O505A	Control	
A-PT-O505B	1x Pair TECK90 / AWG 16	Tray	CP-O30	PT-O505B	Control	
A-AT-O505A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O505A	Control	
C-FV-O523A	10C Multi TECK90 / AWG 14	Tray	CP-O30	FV-O523A	Control	
C-FCV-O530A	6C Multi TECK90 / AWG 14	Tray	LCP-O530A	FCV-O530A	Control	
A-FCV-O530A	2x Pair TECK90 / AWG 16	Tray	LCP-O530A	FCV-O530A	Control	
A-TT-O530A	1x Pair TECK90 / AWG 16	Tray	LCP-O530A	TT-O530A	Control	
C-HTR-O530A	4C Multi TECK90 / AWG 14	Tray	LCP-O530A	HTR-O530A	Control	
A-TT-O530B	1x Pair TECK90 / AWG 16	Tray	LCP-O530A	TT-O530B	Control	
C-CDU-O530A	4C Multi TECK90 / AWG 14	Tray	LCP-O530A	CDU-O530A	Control	
A-PT-O530A	1x Pair TECK90 / AWG 16	Tray	LCP-O530A	PT-O530A	Control	
A-TT-O530C	1x Pair TECK90 / AWG 16	Tray	LCP-O530A	TT-O530C	Control	
C-BLW-O530A	4C Multi TECK90 / AWG 14	Tray	LCP-O530A	BLW-O530A	Control	
A-PT-O530B	1x Pair TECK90 / AWG 16	Tray	LCP-O530A	PT-O530B	Control	
A-AT-O530A	1x Pair TECK90 / AWG 16	Tray	LCP-O530A	AT-O530A	Control	
C-LCP-O530A	10C Multi TECK90 / AWG 14	Tray	CP-O30	LCP-O530A	Control	
C-MCC1A	6C Multi TECK90 / AWG 14	Tray	CP-H10	MCC1A	Control	Addendum 11
C-P-O401A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	P-O401A	Control	
C-MCC1A	6C Multi TECK90 / AWG 14	Tray	CP-H10	MCC1A	Control	Addendum 11
C-P-O402A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	P-O402A	Control	
C-MCC1B	6C Multi TECK90 / AWG 14	Tray	CP-H10	MCC1B	Control	Addendum 11
C-P-O403A	6C Multi TECK90 / AWG 14	Tray	LCP-F01	P-O403A	Control	
C-FS-O404A	2C Multi TECK90 / AWG 14	Tray	LCP-F01	FS-O404A	Control	
C-AT-O404A	4C Multi TECK90 / AWG 14	Tray	LCP-F01	AT-O404A	Control	
A-AT-O404A	1x Pair TECK90 / AWG 16	Tray	LCP-F01	AT-O404A	Control	
C-FV-O410A	10C Multi TECK90 / AWG 14	Tray	PSU-O310A	FV-O410A	Control	
A-TT-O410A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	TT-O410A	Control	
A-FT-O410A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	FT-O410A	Control	
C-FV-O411A	10C Multi TECK90 / AWG 14	Tray	PSU-O310A	FV-O411A	Control	
A-FT-O411A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	FT-O411A	Control	
A-PT-O411A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	PT-O411A	Control	
C-HS-O411A	3C Multi TECK90 / AWG 14	Tray	PSU-O310A	HS-O411A	Control	
A-TT-O411A	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	TT-O411A	Control	
C-FCV-O411A	6C Multi TECK90 / AWG 14	Tray	PSU-O310A	FCV-O411A	Control	
A-FCV-O411A	2x Pair TECK90 / AWG 16	Tray	PSU-O310A	FCV-O411A	Control	
C-SOL-O411A	2C Multi TECK90 / AWG 14	Tray	PSU-O310A	SOL-O411A	Control	
A-CT-O411A	1x Triad TECK90 / AWG 16	Tray	PSU-O310A	CT-O411A	Control	
A-TT-O410B	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	TT-O410B	Control	
A-TT-O411B	1x Pair TECK90 / AWG 16	Tray	PSU-O310A	TT-O411B	Control	
C-FV-O420A	10C Multi TECK90 / AWG 14	Tray	PSU-O320A	FV-O420A	Control	
A-TT-O420A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	TT-O420A	Control	
A-FT-O420A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	FT-O420A	Control	
C-FV-O421A	10C Multi TECK90 / AWG 14	Tray	PSU-O320A	FV-O421A	Control	
A-FT-O421A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	FT-O421A	Control	
A-PT-O421A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	PT-O421A	Control	
C-HS-O421A	3C Multi TECK90 / AWG 14	Tray	PSU-O320A	HS-O421A	Control	
A-TT-O421A	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	TT-O421A	Control	
C-FCV-O421A	6C Multi TECK90 / AWG 14	Tray	PSU-O320A	FCV-O421A	Control	
A-FCV-O421A	2x Pair TECK90 / AWG 16	Tray	PSU-O320A	FCV-O421A	Control	
C-SOL-O421A	2C Multi TECK90 / AWG 14	Tray	PSU-O320A	SOL-O421A	Control	
A-CT-O421A	1x Triad TECK90 / AWG 16	Tray	PSU-O320A	CT-O421A	Control	
A-TT-O420B	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	TT-O420B	Control	
A-TT-O421B	1x Pair TECK90 / AWG 16	Tray	PSU-O320A	TT-O421B	Control	
C-FV-O430A	10C Multi TECK90 / AWG 14	Tray	PSU-O330A	FV-O430A	Control	
A-TT-O430A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	TT-O430A	Control	
A-FT-O430A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	FT-O430A	Control	
C-FV-O431A	10C Multi TECK90 / AWG 14	Tray	PSU-O330A	FV-O431A	Control	
A-FT-O431A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	FT-O431A	Control	
A-PT-O431A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	PT-O431A	Control	
C-HS-O431A	3C Multi TECK90 / AWG 14	Tray	PSU-O330A	HS-O431A	Control	
A-TT-O431A	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	TT-O431A	Control	
C-FCV-O431A	6C Multi TECK90 / AWG 14	Tray	PSU-O330A	FCV-O431A	Control	
A-FCV-O431A	2x Pair TECK90 / AWG 16	Tray	PSU-O330A	FCV-O431A	Control	
C-SOL-O431A	2C Multi TECK90 / AWG 14	Tray	PSU-O330A	SOL-O431A	Control	
A-CT-O431A	1x Triad TECK90 / AWG 16	Tray	PSU-O330A	CT-O431A	Control	
A-TT-O430B	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	TT-O430B	Control	
A-TT-O431B	1x Pair TECK90 / AWG 16	Tray	PSU-O330A	TT-O431B	Control	
C-FV-O310A	2C Multi TECK90 / AWG 14	Tray	PSU-O310A	FV-O310A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-TS-O310A	2C Multi TECK90 / AWG 14	Tray	PSU-O310A	TS-O310A	Control	
C-DS-O310A	2C Multi TECK90 / AWG 14	Tray	PSU-O310A	DS-O310A	Control	
C-FV-O320A	2C Multi TECK90 / AWG 14	Tray	PSU-O320A	FV-O320A	Control	
C-TS-O320A	2C Multi TECK90 / AWG 14	Tray	PSU-O320A	TS-O320A	Control	
C-DS-O320A	2C Multi TECK90 / AWG 14	Tray	PSU-O320A	DS-O320A	Control	
C-FV-O330A	2C Multi TECK90 / AWG 14	Tray	PSU-O330A	FV-O330A	Control	
C-TS-O330A	2C Multi TECK90 / AWG 14	Tray	PSU-O330A	TS-O330A	Control	
C-DS-O330A	2C Multi TECK90 / AWG 14	Tray	PSU-O330A	DS-O330A	Control	
C-SP-O220A	6C Multi TECK90 / AWG 14	Tray	CP-O30	SP-O220A	Control	
C-HS-O220A	3C Multi TECK90 / AWG 14	Tray	CP-O30	HS-O220A	Control	
C-SP-O225A	6C Multi TECK90 / AWG 14	Tray	CP-O30	SP-O225A	Control	
C-HS-O225A	3C Multi TECK90 / AWG 14	Tray	CP-O30	HS-O225A	Control	
C-FS-O221A	2C Multi TECK90 / AWG 14	Tray	CP-O30	FS-O221A	Control	
A-AT-O221A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O221A	Control	
C-FS-O226A	2C Multi TECK90 / AWG 14	Tray	CP-O30	FS-O226A	Control	
A-AT-O226A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O226A	Control	
C-SP-O240A	6C Multi TECK90 / AWG 14	Tray	CP-O30	SP-O240A	Control	
C-HS-O240A	3C Multi TECK90 / AWG 14	Tray	CP-O30	HS-O240A	Control	
C-SP-O245A	6C Multi TECK90 / AWG 14	Tray	CP-O30	SP-O245A	Control	
C-HS-O245A	3C Multi TECK90 / AWG 14	Tray	CP-O30	HS-O245A	Control	
C-FS-O241A	2C Multi TECK90 / AWG 14	Tray	CP-O30	FS-O241A	Control	
A-AT-O241A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O241A	Control	
C-FS-O246A	2C Multi TECK90 / AWG 14	Tray	CP-O30	FS-O246A	Control	
A-AT-O246A	1x Pair TECK90 / AWG 16	Tray	CP-O30	AT-O246A	Control	
C-SLG-R010A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-R010A	Control	
C-SLG-R010B	3C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-R010B	Control	
C-LS-R010A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R010A	Control	
C-LS-R010B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R010B	Control	
C-SLG-R100A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-R100A	Control	
C-SLG-R200A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-R200A	Control	
C-SLG-R300A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-R300A	Control	
C-SLG-R400A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	SLG-R400A	Control	
C-LS-R100A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R100A	Control	
C-LS-R100B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R100B	Control	
C-FV-R100A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R100A	Control	
C-LT-R100D	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R100D	Control	
A-LT-R100D	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R100D	Control	
C-LT-R100E	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R100E	Control	
A-LT-R100E	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R100E	Control	
A-AY-R100C	2x Pair TECK90 / AWG 16	Tray	MCC3A	AY-R100C	Control	
C-HS-R100D	3C Multi TECK90 / AWG 14	Tray	MCC3A	HS-R100D	Control	
C-LS-R200A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R200A	Control	
C-LS-R200B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R200B	Control	
C-FV-R200A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R200A	Control	
C-LT-R200D	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R200D	Control	
A-LT-R200D	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R200D	Control	
C-LT-R200E	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R200E	Control	
A-LT-R200E	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R200E	Control	
A-AY-R200C	2x Pair TECK90 / AWG 16	Tray	MCC3A	AY-R200C	Control	
C-HS-R200D	3C Multi TECK90 / AWG 14	Tray	MCC3A	HS-R200D	Control	
C-LS-R300A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R300A	Control	
C-LS-R300B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R300B	Control	
C-FV-R300A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R300A	Control	
C-LT-R300D	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R300D	Control	
A-LT-R300D	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R300D	Control	
C-LT-R300E	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R300E	Control	
A-LT-R300E	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R300E	Control	
C-HS-R300D	3C Multi TECK90 / AWG 14	Tray	LCP-R21	HS-R300D	Control	
C-LS-R400A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R400A	Control	
C-LS-R400B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R400B	Control	
C-FV-R400A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R400A	Control	
C-LT-R400D	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R400D	Control	
A-LT-R400D	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R400D	Control	
C-LT-R400E	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R400E	Control	
A-LT-R400E	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R400E	Control	
A-AY-R400C	2x Pair TECK90 / AWG 16	Tray	MCC3B	AY-R400C	Control	
C-HS-R400D	3C Multi TECK90 / AWG 14	Tray	LCP-R21	HS-R400D	Control	
C-AT-R001A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R001A	Control	
A-AT-R001A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R001A	Control	
C-FT-R001B	4C Multi TECK90 / AWG 14	Tray	LCP-R21	FT-R001B	Control	
A-FT-R001B	1x Pair TECK90 / AWG 16	Tray	LCP-R21	FT-R001B	Control	
C-HS-R001C	3C Multi TECK90 / AWG 14	Tray	LCP-R001C	HS-R001C	Control	
C-LS-R001A	8C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R001A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-SP-R010A	6C Multi TECK90 / AWG 14	Tray	LCP-R21	SP-R010A	Control	
C-FS-R010A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	FS-R010A	Control	
C-AT-R010A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R010A	Control	
A-AT-R010A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R010A	Control	
C-VT-R021A	2C Multi TECK90 / AWG 14	Tray	MCC3A	VT-R021A	Control	
A-TT-R021x	3x Pair TECK90 / AWG 16	Tray	MCC3A	TT-R021x	Control	
C-HS-R021A	3C Multi TECK90 / AWG 14	Tray	MCC3A	HS-R021A	Control	
C-VSD-R021B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	VSD-R021B	Control	
A-VSD-R021B	2x Pair TECK90 / AWG 16	Tray	LCP-R21	VSD-R021B	Control	
A-ST-R021B	1x Pair TECK90 / AWG 16	Tray	LCP-R21	ST-R021B	Control	
C-SY-R021B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	SY-R021B	Control	
C-VT-R022A	2C Multi TECK90 / AWG 14	Tray	MCC3B	VT-R022A	Control	
A-TT-R022A	5x Pair TECK90 / AWG 16	Tray	MCC3B	TT-R022A	Control	
C-HS-R022A	3C Multi TECK90 / AWG 14	Tray	MCC3B	HS-R022A	Control	
C-VSD-R022A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	VSD-R022A	Control	
A-VSD-R022A	2x Pair TECK90 / AWG 16	Tray	LCP-R21	VSD-R022A	Control	
A-ST-R022A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	ST-R022A	Control	
C-SY-R022A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	SY-R022A	Control	
C-VT-R023A	2C Multi TECK90 / AWG 14	Tray	MCC3A	VT-R023A	Control	
A-TT-R023A	5x Pair TECK90 / AWG 16	Tray	MCC3A	TT-R023A	Control	
C-HS-R023A	3C Multi TECK90 / AWG 14	Tray	MCC3A	HS-R023A	Control	
C-SY-R023A	2C Multi TECK90 / AWG 14	Tray	MCC3A	SY-R023A	Control	
C-LY-R020C	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LY-R020C	Control	
C-LY-R020D	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LY-R020D	Control	
C-LS-R020A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R020A	Control	
C-LS-R020B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R020B	Control	
C-LT-R020A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R020A	Control	
A-LT-R020A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R020A	Control	
C-FV-R021B	6C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R021B	Control	
C-FV-R022B	6C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R022B	Control	
C-FV-R023B	6C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R023B	Control	
C-AT-R024A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R024A	Control	
A-AT-R024A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R024A	Control	
C-PRV-R024A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	PRV-R024A	Control	
C-HV-R021A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	HV-R021A	Control	
C-HV-R022A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	HV-R022A	Control	
C-HV-R023A	3C Multi TECK90 / AWG 14	Tray	LCP-R21	HV-R023A	Control	
C-FV-R024B	6C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R024B	Control	
C-FT-R024A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	FT-R024A	Control	
A-FT-R024A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	FT-R024A	Control	
C-LS-R500A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R500A	Control	
C-LCP-R500A	10C Multi TECK90 / AWG 14	Tray	LCP-R21	LCP-R500A	Control	
C-VS-R500A	2C Multi TECK90 / AWG 14	Tray	LCP-R500A	VS-R500A	Control	
C-AT-R500B	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R500B	Control	
A-AT-R500B	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R500B	Control	
C-AT-R500C	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R500C	Control	
A-AT-R500C	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R500C	Control	
C-LS-R600A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R600A	Control	
C-LCP-R600A	10C Multi TECK90 / AWG 14	Tray	LCP-R21	LCP-R600A	Control	
C-VS-R600A	2C Multi TECK90 / AWG 14	Tray	LCP-R600A	VS-R600A	Control	
C-AT-R600B	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R600B	Control	
A-AT-R600B	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R600B	Control	
C-AT-R600C	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R600C	Control	
A-AT-R600C	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R600C	Control	
C-FT-R730A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	FT-R730A	Control	
A-FT-R730A	1x Pair TECK90 / AWG 16	Tray	LCP-R21	FT-R730A	Control	
C-AT-R730B	4C Multi TECK90 / AWG 14	Tray	LCP-R21	AT-R730B	Control	
A-AT-R730B	1x Pair TECK90 / AWG 16	Tray	LCP-R21	AT-R730B	Control	
C-FV-R730A	6C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R730A	Control	
C-FV-R710A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R710A	Control	
C-MCC3A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC3A	Control	
A-MCC3A	2x Pair TECK90 / AWG 16	Tray	CP-H10	MCC3A	Control	
C-LT-R710D	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R710D	Control	
A-LT-R710D	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R710D	Control	
C-LS-R710A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R710A	Control	
C-LS-R710B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R710B	Control	
C-HS-R710C	3C Multi TECK90 / AWG 14	Tray	LCP-R710C	HS-R710C	Control	
C-V-R700A	4C Multi TECK90 / AWG 14	Tray	LCP-R21	V-R700A	Control	
C-MCC3B	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC3B	Control	
A-MCC3B	2x Pair TECK90 / AWG 16	Tray	CP-H10	MCC3B	Control	
C-LT-R720D	4C Multi TECK90 / AWG 14	Tray	LCP-R21	LT-R720D	Control	
A-LT-R720D	1x Pair TECK90 / AWG 16	Tray	LCP-R21	LT-R720D	Control	
C-LS-R720A	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R720A	Control	

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-LS-R720B	2C Multi TECK90 / AWG 14	Tray	LCP-R21	LS-R720B	Control	
C-FV-R720A	7C Multi TECK90 / AWG 14	Tray	LCP-R21	FV-R720A	Control	
A-TT-I011A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	TT-I011A	Control	
A-AT-I024B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	AT-I024B	Control	
C-FS-I024B	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I024B	Control	
C-PT-I011B	4C Multi TECK90 / AWG 14	Tray	TJB-A11	PT-I011B	Control	
A-PT-I011B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	PT-I011B	Control	
C-FS-I022E	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I022E	Control	
C-FS-I023E	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I023E	Control	
A-TT-I012A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	TT-I012A	Control	
C-PT-I012B	4C Multi TECK90 / AWG 14	Tray	TJB-A11	PT-I012B	Control	
A-PT-I012B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	PT-I012B	Control	
A-AT-I027B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	AT-I027B	Control	
C-FS-I027B	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I027B	Control	
C-HS-I013A	3C Multi TECK90 / AWG 14	Tray	MCC1A	HS-I013A	Control	
C1-MCC1A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC1A	Control	
C-HS-I014A	3C Multi TECK90 / AWG 14	Tray	MCC1A	HS-I014A	Control	
C2-MCC1A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC1A	Control	
C-HS-I015A	3C Multi TECK90 / AWG 14	Tray	MCC1B	HS-I015A	Control	
C-MCC1B	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC1B	Control	
C-HV-I013D	2C Multi TECK90 / AWG 14	Tray	TJB-A11	HV-I013D	Control	
C-FV-I014D	7C Multi TECK90 / AWG 14	Tray	TJB-A11	FV-I014D	Control	
C-HV-I015D	2C Multi TECK90 / AWG 14	Tray	TJB-A11	HV-I015D	Control	
C-FV-I014E	7C Multi TECK90 / AWG 14	Tray	TJB-A11	FV-I014E	Control	
A-AT-I025B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	AT-I025B	Control	
C-FS-I025B	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I025B	Control	
C-FS-I017D	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I017D	Control	
C-FS-I018D	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I018D	Control	
C-FS-I026B	2C Multi TECK90 / AWG 14	Tray	TJB-A11	FS-I026B	Control	
A-AT-I026B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	AT-I026B	Control	
C-FT-P100A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P100A	Control	
A-FT-P100A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P100A	Control	
C-FCV-P100A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P100A	Control	
A-FCV-P100A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P100A	Control	
C-FT-P200A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P200A	Control	
A-FT-P200A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P200A	Control	
C-FCV-P200A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P200A	Control	
A-FCV-P200A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P200A	Control	
C-FT-P300A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P300A	Control	
A-FT-P300A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P300A	Control	
C-FCV-P300A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P300A	Control	
A-FCV-P300A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P300A	Control	
C-FT-P400A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P400A	Control	
A-FT-P400A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P400A	Control	
C-FCV-P400A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P400A	Control	
A-FCV-P400A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P400A	Control	
C-FT-P500A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P500A	Control	
A-FT-P500A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P500A	Control	
C-FCV-P500A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P500A	Control	
A-FCV-P500A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P500A	Control	
C-FT-P600A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P600A	Control	
A-FT-P600A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P600A	Control	
C-FCV-P600A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P600A	Control	
A-FCV-P600A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P600A	Control	
C-FT-P700A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P700A	Control	
A-FT-P700A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P700A	Control	
C-FCV-P700A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P700A	Control	
A-FCV-P700A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P700A	Control	
C-FT-P800A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FT-P800A	Control	
A-FT-P800A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	FT-P800A	Control	
C-FCV-P800A	6C Multi TECK90 / AWG 14	Tray	TJB-A11	FCV-P800A	Control	
A-FCV-P800A	2x Pair TECK90 / AWG 16	Tray	TJB-A11	FCV-P800A	Control	
C-DF-P100A	4C Multi TECK90 / AWG 14	Tray	LCP-P31	DF-P100A	Control	
C-SOL-P120A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P120A	Control	Addendum 11
C-SOL-P120B	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P120B	Control	Addendum 11
C-LT-P100A	4C Multi TECK90 / AWG 14	Tray	CP-P31	LT-P100A	Control	Addendum 11
A-LT-P100A	1x Pair TECK90 / AWG 16	Tray	CP-P31	LT-P100A	Control	Addendum 11
C-SLG-P140A	6C Multi TECK90 / AWG 14	Tray	CP-P31	SLG-P140A	Control	
A-SLG-P140A	2x Pair TECK90 / AWG 16	Tray	CP-P31	SLG-P140A	Control	
C-FV-P110A	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P110A	Control	
C-FV-P110B	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P110B	Control	
C-DF-P200A	4C Multi TECK90 / AWG 14	Tray	LCP-P32	DF-P200A	Control	
C-SOL-P220A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P220A	Control	Addendum 11

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-SOL-P220B	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P220B	Control	Addendum 11
C-LT-P200A	4C Multi TECK90 / AWG 14	Tray	CP-P31	LT-P200A	Control	Addendum 11
A-LT-P200A	1x Pair TECK90 / AWG 16	Tray	CP-P31	LT-P200A	Control	Addendum 11
C-SLG-P240A	6C Multi TECK90 / AWG 14	Tray	CP-P31	SLG-P240A	Control	
A-SLG-P240A	2x Pair TECK90 / AWG 16	Tray	CP-P31	SLG-P240A	Control	
C-FV-P210A	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P210A	Control	
C-FV-P210B	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P210B	Control	
C-DF-P300A	4C Multi TECK90 / AWG 14	Tray	LCP-P33	DF-P300A	Control	
C-SOL-P320A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P320A	Control	Addendum 11
C-SOL-P320B	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P320B	Control	Addendum 11
C-LT-P300A	4C Multi TECK90 / AWG 14	Tray	CP-P31	LT-P300A	Control	Addendum 11
A-LT-P300A	1x Pair TECK90 / AWG 16	Tray	CP-P31	LT-P300A	Control	Addendum 11
C-SLG-P340A	6C Multi TECK90 / AWG 14	Tray	CP-P31	SLG-P340A	Control	
A-SLG-P340A	2x Pair TECK90 / AWG 16	Tray	CP-P31	SLG-P340A	Control	
C-FV-P310A	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P310A	Control	
C-FV-P310B	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P310B	Control	
C-DF-P400A	4C Multi TECK90 / AWG 14	Tray	LCP-P34	DF-P400A	Control	
C-SOL-P420A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P420A	Control	Addendum 11
C-SOL-P420B	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P420B	Control	Addendum 11
C-LT-P400A	4C Multi TECK90 / AWG 14	Tray	CP-P31	LT-P400A	Control	Addendum 11
A-LT-P400A	1x Pair TECK90 / AWG 16	Tray	CP-P31	LT-P400A	Control	Addendum 11
C-SLG-P440A	6C Multi TECK90 / AWG 14	Tray	CP-P31	SLG-P440A	Control	
A-SLG-P440A	2x Pair TECK90 / AWG 16	Tray	CP-P31	SLG-P440A	Control	
C-FV-P410A	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P410A	Control	
C-FV-P410B	7C Multi TECK90 / AWG 14	Tray	CP-P31	FV-P410B	Control	
C-DF-P500A	4C Multi TECK90 / AWG 14	Tray	LCP-P35	DF-P500A	Control	
C-SOL-P520A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P520A	Control	Addendum 11
C-SOL-P520B	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P520B	Control	Addendum 11
C-LT-P500A	4C Multi TECK90 / AWG 14	Tray	CP-P32	LT-P500A	Control	Addendum 11
A-LT-P500A	1x Pair TECK90 / AWG 16	Tray	CP-P32	LT-P500A	Control	Addendum 11
C-SLG-P540A	6C Multi TECK90 / AWG 14	Tray	TJB-P34	SLG-P540A	Control	Addendum 11
A-SLG-P540A	2x Pair TECK90 / AWG 16	Tray	TJB-P34	SLG-P540A	Control	Addendum 11
C-FV-P510A	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P510A	Control	Addendum 11
C-FV-P510B	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P510B	Control	Addendum 11
C-DF-P600A	4C Multi TECK90 / AWG 14	Tray	LCP-P36	DF-P600A	Control	
C-SOL-P620A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P620A	Control	Addendum 11
C-SOL-P620B	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P620B	Control	Addendum 11
C-LT-P600A	4C Multi TECK90 / AWG 14	Tray	CP-P32	LT-P600A	Control	Addendum 11
A-LT-P600A	1x Pair TECK90 / AWG 16	Tray	CP-P32	LT-P600A	Control	Addendum 11
C-SLG-P640A	6C Multi TECK90 / AWG 14	Tray	TJB-P34	SLG-P640A	Control	Addendum 11
A-SLG-P640A	2x Pair TECK90 / AWG 16	Tray	TJB-P34	SLG-P640A	Control	Addendum 11
C-FV-P610A	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P610A	Control	Addendum 11
C-FV-P610B	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P610B	Control	Addendum 11
C-DF-P700A	4C Multi TECK90 / AWG 14	Tray	LCP-P37	DF-P700A	Control	
C-SOL-P720A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P720A	Control	Addendum 11
C-SOL-P720B	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P720B	Control	Addendum 11
C-LT-P700A	4C Multi TECK90 / AWG 14	Tray	CP-P32	LT-P700A	Control	Addendum 11
A-LT-P700A	1x Pair TECK90 / AWG 16	Tray	CP-P32	LT-P700A	Control	Addendum 11
C-SLG-P740A	6C Multi TECK90 / AWG 14	Tray	TJB-P34	SLG-P740A	Control	Addendum 11
A-SLG-P740A	2x Pair TECK90 / AWG 16	Tray	TJB-P34	SLG-P740A	Control	Addendum 11
C-FV-P710A	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P710A	Control	Addendum 11
C-FV-P710B	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P710B	Control	Addendum 11
C-DF-P800A	4C Multi TECK90 / AWG 14	Tray	LCP-P38	DF-P800A	Control	
C-SOL-P820A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P820A	Control	Addendum 11
C-SOL-P820B	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P820B	Control	Addendum 11
C-LT-P800A	4C Multi TECK90 / AWG 14	Tray	CP-P32	LT-P800A	Control	Addendum 11
A-LT-P800A	1x Pair TECK90 / AWG 16	Tray	CP-P32	LT-P800A	Control	Addendum 11
C-SLG-P840A	6C Multi TECK90 / AWG 14	Tray	TJB-P34	SLG-P840A	Control	Addendum 11
A-SLG-P840A	2x Pair TECK90 / AWG 16	Tray	TJB-P34	SLG-P840A	Control	Addendum 11
C-FV-P810A	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P810A	Control	Addendum 11
C-FV-P810B	7C Multi TECK90 / AWG 14	Tray	CP-P32	FV-P810B	Control	Addendum 11
A-P-P010A	3x Pair TECK90 / AWG 16	Tray	LCP-P010A	P-P010A	Control	
C-HV-P010C	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P010C	Control	Addendum 11
A-P-P020A	3x Pair TECK90 / AWG 16	Tray	LCP-P020A	P-P020A	Control	
C-HV-P020C	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P020C	Control	Addendum 11
A-P-P030A	3x Pair TECK90 / AWG 16	Tray	LCP-P030A	P-P030A	Control	
C-FV-P020D	7C Multi TECK90 / AWG 14	Tray	TJB-P13	FV-P020D	Control	Addendum 11
C-FV-P020E	7C Multi TECK90 / AWG 14	Tray	TJB-P13	FV-P020E	Control	Addendum 11
C-HV-P030C	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P030C	Control	Addendum 11
C-FT-P001A	4C Multi TECK90 / AWG 14	Tray	TJB-P33	FT-P001A	Control	Addendum 11
A-FT-P001A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	FT-P001A	Control	Addendum 11
A-PT-P001A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	PT-P001A	Control	Addendum 11
C-LT-P001A	4C Multi TECK90 / AWG 14	Tray	TJB-P33	LT-P001A	Control	Addendum 11

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
A-LT-P001A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	LT-P001A	Control	Addendum 11
C-LS-P001A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	LS-P001A	Control	
C-PS-P001A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	PS-P001A	Control	
A-TT-P001A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	TT-P001A	Control	
C-FV-P001A	7C Multi TECK90 / AWG 14	Tray	TJB-P33	FV-P001A	Control	
C-SOL-P001A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P001A	Control	
C-FT-P002A	4C Multi TECK90 / AWG 14	Tray	TJB-P33	FT-P002A	Control	
A-FT-P002A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	FT-P002A	Control	
A-PT-P002A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	PT-P002A	Control	
C-LT-P002A	4C Multi TECK90 / AWG 14	Tray	TJB-P33	LT-P002A	Control	
A-LT-P002A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	LT-P002A	Control	
C-LS-P002A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	LS-P002A	Control	
C-PS-P002A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	PS-P002A	Control	
A-TT-P002A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	TT-P002A	Control	
C-SOL-P002A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	SOL-P002A	Control	
A-P-P040A	3x Pair TECK90 / AWG 16	Tray	LCP-P040A	P-P040A	Control	
C-HV-P040C	2C Multi TECK90 / AWG 14	Tray	TJB-P14	HV-P040C	Control	Addendum 11
A-P-P050A	3x Pair TECK90 / AWG 16	Tray	LCP-P050A	P-P050A	Control	
C-HV-P050C	2C Multi TECK90 / AWG 14	Tray	TJB-P14	HV-P050C	Control	Addendum 11
A-P-P060A	3x Pair TECK90 / AWG 16	Tray	TJB-P14	P-P060A	Control	Addendum 11
C-FV-P050D	7C Multi TECK90 / AWG 14	Tray	TJB-P13	FV-P050D	Control	Addendum 11
C-FV-P050E	7C Multi TECK90 / AWG 14	Tray	TJB-P13	FV-P050E	Control	Addendum 11
C-HV-P060C	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P060C	Control	Addendum 11
C-FT-P003A	4C Multi TECK90 / AWG 14	Tray	TJB-P34	FT-P003A	Control	
A-FT-P003A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	FT-P003A	Control	
A-PT-P003A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	PT-P003A	Control	
C-LT-P003A	4C Multi TECK90 / AWG 14	Tray	TJB-P34	LT-P003A	Control	
A-LT-P003A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	LT-P003A	Control	
C-LS-P003A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	LS-P003A	Control	
C-PS-P003A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	PS-P003A	Control	
A-TT-P003A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	TT-P003A	Control	
C-SOL-P003A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P003A	Control	
C-FT-P004A	4C Multi TECK90 / AWG 14	Tray	TJB-P34	FT-P004A	Control	
A-FT-P004A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	FT-P004A	Control	
A-PT-P004A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	PT-P004A	Control	
C-LT-P004A	4C Multi TECK90 / AWG 14	Tray	TJB-P34	LT-P004A	Control	
A-LT-P004A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	LT-P004A	Control	
C-LS-P004A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	LS-P004A	Control	
C-PS-P004A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	PS-P004A	Control	
A-TT-P004A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	TT-P004A	Control	
C-SOL-P004A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	SOL-P004A	Control	
C-LCP-P910A	4C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-P910A	Control	
C-LCP-P920A	4C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-P920A	Control	
A-PT-P900A	1x Pair TECK90 / AWG 16	Tray	CP-H30	PT-P900A	Control	
C-LS-P970A	2C Multi TECK90 / AWG 14	Tray	TJB-P33	LS-P970A	Control	
C-LT-P970A	4C Multi TECK90 / AWG 14	Tray	TJB-P33	LT-P970A	Control	
A-LT-P970A	1x Pair TECK90 / AWG 16	Tray	TJB-P33	LT-P970A	Control	
C-LS-P971A	2C Multi TECK90 / AWG 14	Tray	TJB-P34	LS-P971A	Control	
C-LT-P971A	4C Multi TECK90 / AWG 14	Tray	TJB-P34	LT-P971A	Control	
A-LT-P971A	1x Pair TECK90 / AWG 16	Tray	TJB-P34	LT-P971A	Control	
C-FS-P975A	2C Multi TECK90 / AWG 14	Tray	TJB-P13	FS-P975A	Control	Addendum 11
A-AT-P975A	1x Pair TECK90 / AWG 16	Tray	TJB-P13	AT-P975A	Control	Addendum 11
A-AT-P976A	1x Pair TECK90 / AWG 16	Tray	TJB-P13	AT-P976A	Control	Addendum 11
A-PT-P930A	1x Pair TECK90 / AWG 16	Tray	TJB-P13	PT-P930A	Control	Addendum 11
A-PT-P930B	1x Pair TECK90 / AWG 16	Tray	TJB-P13	PT-P930B	Control	Addendum 11
C-HS-P931A	3C Multi TECK90 / AWG 14	Tray	MCC2A	HS-P931A	Control	
C1-MCC2A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2A	Control	
C-HV-P931E	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P931E	Control	Addendum 11
C-HS-P932A	3C Multi TECK90 / AWG 14	Tray	MCC2A	HS-P932A	Control	
C2-MCC2A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2A	Control	
C-HV-P932E	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P932E	Control	Addendum 11
A-PT-P940A	1x Pair TECK90 / AWG 16	Tray	TJB-P13	PT-P940A	Control	Addendum 11
A-PT-P940B	1x Pair TECK90 / AWG 16	Tray	TJB-P13	PT-P940B	Control	Addendum 11
C-HS-P941A	3C Multi TECK90 / AWG 14	Tray	MCC2A	HS-P941A	Control	
C3-MCC2A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2A	Control	
C-HV-P941E	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P941E	Control	Addendum 11
C-HS-P942A	3C Multi TECK90 / AWG 14	Tray	MCC2A	HS-P942A	Control	
C4-MCC2A	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2A	Control	
C-HV-P942E	2C Multi TECK90 / AWG 14	Tray	TJB-P13	HV-P942E	Control	Addendum 11
C-FT-P990A	4C Multi TECK90 / AWG 14	Tray	TJB-P13	FT-P990A	Control	Addendum 11
A-FT-P990A	1x Pair TECK90 / AWG 16	Tray	TJB-P13	FT-P990A	Control	Addendum 11
A-PT-P950A	1x Pair TECK90 / AWG 16	Tray	TJB-P13	PT-P950A	Control	Addendum 11
A-PT-P950B	1x Pair TECK90 / AWG 16	Tray	TJB-P13	PT-P950B	Control	Addendum 11

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-HS-P951A	3C Multi TECK90 / AWG 14	Tray	MCC2B	HS-P951A	Control	
C1-MCC2B	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2B	Control	
C-HV-P951E	2C Multi TECK90 / AWG 14	Tray	TJB-P14	HV-P951E	Control	Addendum 11
C-HS-P952A	3C Multi TECK90 / AWG 14	Tray	MCC2B	HS-P952A	Control	
C2-MCC2B	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2B	Control	
C-HV-P952E	2C Multi TECK90 / AWG 14	Tray	TJB-P14	HV-P952E	Control	Addendum 11
A-PT-P960A	1x Pair TECK90 / AWG 16	Tray	TJB-P14	PT-P960A	Control	Addendum 11
A-PT-P960B	1x Pair TECK90 / AWG 16	Tray	TJB-P14	PT-P960B	Control	Addendum 11
C-HS-P961A	3C Multi TECK90 / AWG 14	Tray	MCC2B	HS-P961A	Control	
C3-MCC2B	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2B	Control	
C-HV-P961E	2C Multi TECK90 / AWG 14	Tray	TJB-P14	HV-P961E	Control	Addendum 11
C-HS-P962A	3C Multi TECK90 / AWG 14	Tray	MCC2B	HS-P962A	Control	
C4-MCC2B	8C Multi TECK90 / AWG 14	Tray	CP-H10	MCC2B	Control	
C-HV-P962E	2C Multi TECK90 / AWG 14	Tray	TJB-P14	HV-P962E	Control	Addendum 11
C-FT-P993A	4C Multi TECK90 / AWG 14	Tray	TJB-P14	FT-P993A	Control	Addendum 11
A-FT-P993A	1x Pair TECK90 / AWG 16	Tray	TJB-P14	FT-P993A	Control	Addendum 11
C-LT-P980A	4C Multi TECK90 / AWG 14	Tray	TJB-A11	LT-P980A	Control	
A-LT-P980A	1x Pair TECK90 / AWG 16	Tray	TJB-A11	LT-P980A	Control	
C-LT-P980B	4C Multi TECK90 / AWG 14	Tray	TJB-A11	LT-P980B	Control	Addendum 3
A-LT-P980B	1x Pair TECK90 / AWG 16	Tray	TJB-A11	LT-P980B	Control	Addendum 3
C-AE-P981	2C Multi TECK90 / AWG 14	Tray	LCP-P981A	AE-P981	Control	Addendum 3
C-AE-P982A	2C Multi TECK90 / AWG 14	Tray	LCP-P981A	AE-P982A	Control	Addendum 3
C-AE-P983	2C Multi TECK90 / AWG 14	Tray	LCP-P983A	AE-P983	Control	Addendum 3
C-AY-H501A	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	AY-H501A	Control	Addendum 3
C-AY-H502A	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	AY-H502A	Control	Addendum 3
C-LS-H500C	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H500C	Control	
C-LS-H500D	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H500D	Control	
C-LS-H500B	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H500B	Control	
C-LS-H500A	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H500A	Control	
C-LCP-H500A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H500A	Control	
C-AY-H511A	2C Multi TECK90 / AWG 14	Tray	LCP-H510A	AY-H511A	Control	Addendum 3
C-AY-H512A	2C Multi TECK90 / AWG 14	Tray	LCP-H510A	AY-H512A	Control	Addendum 3
C-LS-H510C	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H510C	Control	
C-LS-H510D	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H510D	Control	
C-LS-H510B	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H510B	Control	
C-LS-H510A	2C Multi TECK90 / AWG 14	Tray	LCP-H500A	LS-H510A	Control	
C-LCP-H510A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H510A	Control	
C-LS-H520A	2C Multi TECK90 / AWG 14	Tray	LCP-H510A	LS-H520A	Control	
C-LS-H520B	2C Multi TECK90 / AWG 14	Tray	LCP-H521A	LS-H520B	Control	
C-LCP-H521A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H521A	Control	
C-AY-H531A	2C Multi TECK90 / AWG 14	Tray	LCP-H530A	AY-H531A	Control	Addendum 3
C-AY-H532A	2C Multi TECK90 / AWG 14	Tray	AY-H531A	AY-H532A	Control	Addendum 3
C-P-H701A	2C Multi TECK90 / AWG 14	Tray	CP-H10	P-H701A	Control	
A-PT-H701A	1x Pair TECK90 / AWG 16	Tray	CP-H10A	PT-H701A	Control	Addendum 3
A-PT-H704A	1x Pair TECK90 / AWG 16	Tray	CP-H10A	PT-H704A	Control	Addendum 3
C-LCP-H101A	4C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H101A	Control	Addendum 3
C-FS-H130A	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	FS-H130A	Control	Addendum 3
C-HV-H152B	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H152B	Control	Addendum 3
C-HV-H130A	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H130A	Control	Addendum 3
C-HV-H130C	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H130C	Control	Addendum 3
C-HV-H110A	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H110A	Control	Addendum 3
C-HV-H110C	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H110C	Control	Addendum 3
C-HV-H150B	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H150B	Control	Addendum 3
C-FS-H120A	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	FS-H120A	Control	Addendum 3
C-HV-H105B	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H105B	Control	Addendum 3
C-HV-H105C	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H105C	Control	Addendum 3
C-HV-H105A	2C Multi TECK90 / AWG 14	Tray	LCP-H101A	HV-H105A	Control	Addendum 3
C-LCP-H110A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H110A	Control	
C1-LCP-H110A	8C Multi TECK90 / AWG 14	Tray	LCP-H101A	LCP-H110A	Control	Addendum 3
C-LCP-H130A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H130A	Control	Addendum 3
C-LT-H400A	4C Multi TECK90 / AWG 14	Tray	CP-H10	LT-H400A	Control	Addendum 3
A-LT-H400A	1x Pair TECK90 / AWG 16	Tray	CP-H10	LT-H400A	Control	Addendum 3
C-LT-H400B	4C Multi TECK90 / AWG 14	Tray	CP-H10	LT-H400B	Control	Addendum 3
A-LT-H400B	1x Pair TECK90 / AWG 16	Tray	CP-H10	LT-H400B	Control	Addendum 3
C-AE-H410A	2C Multi TECK90 / AWG 14	Tray	LCP-H410A	AE-H410A	Control	Addendum 3
C-LCP-H410A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H410A	Control	Addendum 3
C-AE-H420A	2C Multi TECK90 / AWG 14	Tray	LCP-H420A	AE-H420A	Control	Addendum 3
C-LCP-H420A	8C Multi TECK90 / AWG 14	Tray	CP-H10	LCP-H420A	Control	Addendum 3
C-PS-H602A	2C Multi TECK90 / AWG 14	Tray	LCP-H600B	PS-H602A	Control	Addendum 3
C-PS-H602B	2C Multi TECK90 / AWG 14	Tray	LCP-H600B	PS-H602B	Control	Addendum 3
C-V-600A	2C Multi TECK90 / AWG 14	Tray	LCP-H600B	V-600A	Control	Addendum 3
C-V-600C	2C Multi TECK90 / AWG 14	Tray	PS-H602A	V-600C	Control	Addendum 3
C-LCP-H600B	8C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H600B	Control	Addendum 3

CABLE NUMBER	CABLE TYPE	CABLE ROUTING	ORIGIN	DESTINATION	DESCRIPTION	REMARKS
C-PS-H601A	2C Multi TECK90 / AWG 14	Tray	LCP-H600A	PS-H601A	Control	Addendum 3
C-PS-H601B	2C Multi TECK90 / AWG 14	Tray	LCP-H600A	PS-H601B	Control	Addendum 3
C-V-601A	2C Multi TECK90 / AWG 14	Tray	LCP-H600A	V-601A	Control	Addendum 3
C-V-601C	2C Multi TECK90 / AWG 14	Tray	PS-H601A	V-601C	Control	Addendum 3
C-LCP-H600A	8C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H600A	Control	Addendum 3
C-PS-H605A	2C Multi TECK90 / AWG 14	Tray	CP-H30	PS-H605A	Control	Addendum 3
C-PS-H605B	2C Multi TECK90 / AWG 14	Tray	CP-H30	PS-H605B	Control	Addendum 3
C-LCP-H32A	50C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
G-LCP-H32A	50C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
C-LCP-H32A	50C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
G-LCP-H32A	50C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
C-LCP-H32A	50C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
G-LCP-H32A	50C Multi TECK90 / AWG 14	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
A-LCP-H32A	50x Pair TECK90 / AWG 16	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
A-LCP-H32A	50x Pair TECK90 / AWG 16	Tray	CP-H30	LCP-H32A	Control	Retagged, Addendum 13
C-HCP-H030A	50C Multi TECK90 / AWG 14	Tray	CP-H30	HCP-H030A	Control	Addendum 13
C-HCP-H030A	50C Multi TECK90 / AWG 14	Tray	CP-H30	HCP-H030A	Control	Addendum 13
C-HCP-H030A	50C Multi TECK90 / AWG 14	Tray	CP-H30	HCP-H030A	Control	Addendum 13
C-HCP-H030A	50C Multi TECK90 / AWG 14	Tray	CP-H30	HCP-H030A	Control	Addendum 13
C-HCP-H030A	50C Multi TECK90 / AWG 14	Tray	CP-H30	HCP-H030A	Control	Addendum 13
C-HCP-H030A	50C Multi TECK90 / AWG 14	Tray	CP-H30	HCP-H030A	Control	Addendum 13
A-HCP-H030A	50x Pair TECK90 / AWG 16	Tray	CP-H30	HCP-H030A	Control	Addendum 13
A-HCP-H030A	50x Pair TECK90 / AWG 16	Tray	CP-H30	HCP-H030A	Control	Addendum 13
G-LCP-H31	50C Multi TECK90 / AWG 14	Tray	LCP-H32A	LCP-H31	Control	Deleted, Addendum 13
C-LCP-H31	50C Multi TECK90 / AWG 14	Tray	LCP-H32A	LCP-H31	Control	Deleted, Addendum 13
G-LCP-H31	50C Multi TECK90 / AWG 14	Tray	LCP-H32A	LCP-H31	Control	Deleted, Addendum 13
C-LCP-H32	50C Multi TECK90 / AWG 14	Tray	LCP-H32A	LCP-H32	Control	Deleted, Addendum 13
G-LCP-H32	50C Multi TECK90 / AWG 14	Tray	LCP-H32A	LCP-H32	Control	Deleted, Addendum 13
C-LCP-H32	50C Multi TECK90 / AWG 14	Tray	LCP-H32A	LCP-H32	Control	Deleted, Addendum 13
A-LCP-H31	50x Pair TECK90 / AWG 16	Tray	LCP-H32A	LCP-H31	Control	Deleted, Addendum 13
A-LCP-H32	50x Pair TECK90 / AWG 16	Tray	LCP-H32A	LCP-H32	Control	Deleted, Addendum 13