


**Typical Glulam Beam Repairs**  
 Scale: 1/2" = 1'-0"

- EXTENT OF GLULAM REPAIR WORK**
1. Remove all deteriorated & soft wood (limited to all exterior exposed glulam beams as shown on SK3)
  2. Patch all demolished wood with similar species & grade as original & make good as new condition.
  3. Restain ALL exposed glulam beams (exterior of building only) with an epoxy-based stain. Finish to be consistent & match interior color. Provide a mock-up sample & receive approval from Contract Administrator prior to application on glulam beams.

Extent of removal of deteriorated wood to be at the sole opinion of the Contract Administrator. The area of wood repairs on glulam beams to be limited to areas as shown on SK-3.

**SK-4**  
 Glulam Beam Repairs  
 Transcona Centennial Pool  
 1101 Wabasha Street  
 Winnipeg MB



**GC ENGINEERING LTD.**  
 675 ELM ST.  
 WINNIPEG MB R3M 3N8  
 PH 793-3948 FAX 487-4616  
 EMAIL CALGRAY@MTS.NET