

PART 1 GENERAL

1.1 SUMMARY

- .1 Section Includes:
 - .1 Vibration isolation materials and components for their installation.
 - .2 It is expected that vibration isolation systems be provided by the manufacturer of the packaged HVAC equipment including all air handling units and supply and exhaust fans. Preference shall be made to achieve the necessary vibration control in air handling units through internal isolation of the rotating equipment.

1.2 REFERENCES

- .1 Health Canada/Workplace Hazardous Materials Information System (WHMIS)
 - .1 Material Safety Data Sheets (MSDS).
- .2 National Building Code of Canada (NBC) - 1995

1.3 SUBMITTALS

- .1 Submittals: in accordance with Section 01 33 00- Submittal Procedures.
 - .1 Submit manufacturer's printed product literature, specifications and datasheet in accordance with Section 01 33 00 - Submittal Procedures. Include product characteristics, performance criteria, and limitations.
 - .1 Submit copies of Workplace Hazardous Materials Information System (WHMIS) Material Safety Data Sheets (MSDS) in accordance with Section 01 33 00 - Submittal Procedures.
 - .2 Submit shop drawings in accordance with Section 01 33 00 - Submittal Procedures.
 - .1 Provide system shop drawings complete with performance and product data.
 - .3 Quality assurance submittals: submit following in accordance with Section 01 33 00 - Submittal Procedures.
 - .1 Certificates: submit certificates signed by manufacturer certifying that materials comply with specified performance characteristics and physical properties.
 - .2 Instructions: submit manufacturer's installation instructions.
-

1.4 QUALITY ASSURANCE

- .1 Health and Safety:
 - .1 Do construction occupational health and safety in accordance with Contractor's COR Safety Program and requirements of authority-having-jurisdiction.

1.5 DELIVERY, STORAGE, AND HANDLING

- .1 Packing, shipping, handling and unloading:
 - .1 Deliver, store and handle materials in accordance with manufacturer's written instructions.

PART 2 PRODUCTS

2.1 GENERAL

- .1 Size and shape of bases type and performance of vibration isolation as indicated.

2.2 ELASTOMERIC PADS

- .1 Type EP1 - neoprene waffle or ribbed; 9 mm minimum thick; 50 durometer; maximum loading 350 kPa.
- .2 Type EP2 - rubber waffle or ribbed; 9 mm minimum thick; 30 durometer natural rubber; maximum loading 415 kPa.
- .3 Type EP3 - neoprene-steel-neoprene; 9 mm minimum thick neoprene bonded to 1.71 mm steel plate; 50 durometer neoprene, waffle or ribbed; holes sleeved with isolation washers; maximum loading 350 kPa.
- .4 Type EP4 - rubber-steel-rubber; 9 mm minimum thick rubber bonded to 1.71 mm steel plate; 30 durometer natural rubber, waffle or ribbed; holes sleeved with isolation washers; maximum loading 415 kPa.

2.3 ELASTOMERIC MOUNTS

- .1 Type M1 - colour coded; neoprene in shear; maximum durometer of 60; threaded insert and two bolt-down holes; ribbed top and bottom surfaces.

2.4 SPRINGS

- .1 Design stable springs: ratio of lateral to axial stiffness is equal to or greater than 1.2 times ratio of static deflection to working height. Select for 50% travel beyond rated load. Units complete with levelling devices.
-

-
- .2 Ratio of height when loaded to diameter of spring between 0.8 to 1.0.
 - .3 Cadmium plate for outdoor and high humidity installations.
 - .4 Colour code springs.

2.5 SPRING MOUNT

- .1 Zinc or cadmium plated hardware; housings coated with rust resistant paint.
- .2 Type M2 - stable open spring: support on bonded 6 mm minimum thick ribbed neoprene or rubber friction and acoustic pad.
- .3 Type M3 - stable open spring: 6 mm minimum thick ribbed neoprene or rubber friction and acoustic pad, bonded under isolator and on isolator top plate; levelling bolt for rigidly mounting to equipment.
- .4 Type M4 - restrained stable open spring: supported on bonded 6 mm minimum thick ribbed neoprene or rubber friction and acoustic pad; built-in resilient limit stops, removable spacer plates.
- .5 Type M5 - enclosed spring mounts with snubbers for isolation up to 950 kg maximum.

2.6 HANGERS

- .1 Colour coded springs, rust resistant, painted box type hangers. Arrange to permit hanger box or rod to move through a 30 degrees arc without metal to metal contact.
- .2 Type H1 - neoprene - in-shear, moulded with rod isolation bushing which passes through hanger box.
- .3 Type H2 - stable spring, elastomeric washer, cup with moulded isolation bushing which passes through hanger box.
- .4 Type H3 - stable spring, elastomeric element, cup with moulded isolation bushing which passes through hanger box.
- .5 Type H4 - stable spring, elastomeric element with precompression washer and nut with deflection indicator.

2.7 STRUCTURAL BASES (WHERE NOT PROVIDED BY EQUIPMENT)

- .1 Type B1 - Prefabricated steel base: integrally welded on sizes up to 2400 mm on smallest dimension, split for field welding on sizes over 2400 mm on smallest dimension and reinforced for alignment of drive and driven equipment; without supplementary hold down devices; complete with isolation element attached to
-

base brackets arranged to minimize height; pre-drilled holes to receive equipment anchor bolts; and complete with adjustable built-in motor slide rail and jacking bolts.

- .2 Type B2 - Steel rail base: structural steel, positioned for alignment of drive and driven equipment; without supplementary hold down devices; complete with isolation element attached to base brackets arranged to minimize height; and pre-drilled holes to receive equipment anchor bolts.
- .3 Bases to clear housekeeping pads by 100 mm minimum.

PART 3 EXECUTION

3.1 MANUFACTURER'S INSTRUCTIONS

- .1 Compliance: comply with manufacturer's written recommendations or specifications, including product technical bulletins, handling, storage and installation instructions, and datasheet.

3.2 INSTALLATION

- .1 Install vibration isolation equipment in accordance with manufacturer's instructions and adjust mountings to level equipment.
 - .2 Ensure piping, ducting and electrical connections to isolated equipment do not reduce system flexibility and that piping, conduit and ducting passage through walls and floors do not transmit vibrations.
 - .3 Unless indicated otherwise, support piping connected to isolated equipment with spring mounts or spring hangers with 25 mm minimum static deflection as follows:
 - .1 Up to NPS4: first 3 points of support. NPS5 to NPS8: first 4 points of support. NPS10 and Over: first 6 points of support.
 - .2 First point of support: static deflection of twice deflection of isolated equipment, but not more than 50 mm.
 - .4 Where isolation is bolted to floor use vibration isolation rubber washers.
 - .5 Block and shim level bases so that ductwork and piping connections can be made to rigid system at operating level, before isolator adjustment is made. Ensure that there is no physical contact between isolated equipment and building structure.
-

3.3 CLEANING

- .1 Proceed in accordance with Section 01 74 00 - Cleaning and Waste Management.
- .2 Upon completion and verification of performance of installation, remove surplus materials, excess materials, rubbish, tools and equipment.

END OF SECTION
