# HANGERS AND SUPPORTS FOR ELECTRICAL SYSTEMS

# 1. GENERAL

#### 1.1 Related Sections

.1 Section 26 05 00 - Common Work Results - Electrical.

# 2. PRODUCTS

# 2.1 Support Channels

.1 U shape, size 41.3mm x 41.3mm, 12 gauge thick, surface mounted, suspended.

#### 3. EXECUTION

# 3.1 Installation

- .1 Secure equipment to solid masonry, tile and plaster surfaces with lead anchors or nylon shields.
- .2 Secure equipment to poured concrete with expandable inserts.
- .3 Secure equipment to hollow masonry walls or suspended ceilings with toggle bolts.
- .4 Secure surface mounted equipment with twist clip fasteners to inverted T bar ceilings. Ensure that T bars are adequately supported to carry weight of equipment specified before installation.
- .5 Support equipment, conduit or cables using clips, spring loaded bolts, cable clamps designed as accessories to basic channel members.
- .6 Fasten exposed conduit or cables to building construction or support system using straps.
  - .1 One-hole steel straps to secure surface conduits and cables 51 mm and smaller.
  - .2 Two-hole steel straps for conduits and cables larger than 51 mm.
  - .3 Beam clamps to secure conduit to exposed steel work.
- .7 Suspended support systems.
  - .1 Support individual cable or conduit runs with 6.4 mm dia threaded rods and spring clips.
  - .2 Support 2 or more cables or conduits on channels supported by minimum 6.4 mm dia threaded rod hangers where direct fastening to building construction is impractical.
- .8 For surface mounting of two or more conduits use channels at 600 m on centre spacing.
- .9 Provide metal brackets, frames, hangers, clamps and related types of support structures where indicated or as required to support conduit and cable runs.

# HANGERS AND SUPPORTS FOR ELECTRICAL SYSTEMS

- .10 Ensure adequate support for raceways and cables dropped vertically to equipment where there is no wall support.
- .11 Do not use wire lashing or perforated strap to support or secure raceways or cables.
- .12 Do not use supports or equipment installed for other trades for conduit or cable support except with permission of other trade and approval of Contract Administrator.
- .13 Install fastenings and supports as required for each type of equipment cables and conduits, and in accordance with manufacturer's installation recommendations.

**END OF SECTION**