



FIELD (12" O.C.)

1. PARALLEL RIBBONS AT 12" O.C.
2. REFER TO INSULATION ADHESIVE PRODUCT DATA SHEET FOR RIBBON WIDTH.



PERMETER PRESCRIPTIVE ENHANCEMENT



1. PARALLEL RIBBONS AT 6" O.C.
2. REFER TO INSULATION ADHESIVE PRODUCT DATA SHEET FOR RIBBON WIDTH.



CORNER PRESCRIPTIVE ENHANCEMENT

1. PARALLEL RIBBONS AT 4" O.C.
2. REFER TO INSULATION ADHESIVE PRODUCT DATA SHEET FOR RIBBON WIDTH.

1. IF APPLYING ADHESIVE TO ADHERE A COMPOSITE PANEL WHOSE UNDERFACE IS NO MORE THAN 900mm (36 in), USE THE FOLLOWING Z PATTERN



NOTES:

1. FOR MOST PROJECTS, THE REQUIRED AMOUNT OF ADHESIVE VARIES FROM ZONE TO ZONE.
2. FOR MORE DETAILS, CONSULT THE WIND UPLIFT RESISTANCE TESTING REPORTS ACCORDING TO CANADIAN STANDARD CSA A123.21-10 OR PUBLICATIONS ACCORDING TO FM 4470 (ROOFNAV DATABASE) INCLUDING RECOMMENDATIONS FOR CORNERS AND PERIMETERS LISTED IN THE PLPDS 1-29 FROM FACTORY MUTUAL.
3. DURING INSTALLATION, IT IS IMPORTANT TO IMMEDIATELY PLACE THE BOARDS OVER THE APPLIED ADHESIVE.
4. TRY TO AVOID UNEVEN SURFACES, TO ENSURE PROPER ADHESION TO THE SUBSTRATE.
5. WHEN APPLYING ADHESIVE, USE A Z-PATTERN TO FACILITATE AND SPEED UP THE INSTALLATION OF BOARDS. USE A Z PATTERN ABOUT 2.4 M TO 3.6 M (8 FT TO 12 FT) LONG.

#633-2023 ROOF REPLACEMENT  
WFPS STATION 10

Project Address 1501 Church Avenue  
Winnipeg, Manitoba

Client JDB Building Envelope  
Specialists  
Winnipeg, Manitoba  
www.buildingenvelope.biz  
204.371.0996

Drawing  
ADHESIVE LAYOUT PLAN