

GENERAL NOTES

FOR THE INSULATION & COMPOSITE BALLAST EACH BOARD WITH A MIN OF FOUR 40 LB [18KG] BALLASTS.

2. THE ADHESIVE MUST BE APPLIED TO THE UINDERSIDE OF THE BOARD.

3. APPLY ONE 3/4" [19mm] BEAD OF ADHESIVE AROUND THE ENTIRE PERIMETER OF THE BOARD 6" [152mm] IN FROM THE EDGE OF THE BOARD.

4. REFER TO SHEET A 1.05 FOR THE FASTENING ZONE PLAN.

\bigcirc KEY NOTES

FIELD & PERIMETER (ZONE 1 & 2)

1. APPLY TWO ADDITIONAL 3/4" [19mm] BEADS RUNNING LENGTHWISE AND SPACED EQUALLY OVER THE WIDTH OF THE BOARD, (12" [305mm] SPACING ±

2. APPLY FIVE ADDITIONAL 3/4" [19mm] BEADS RUNNING LENGTHWISE AND SPACED EQUALLY OVER THE WIDTH OF THE BOARD, (6" [152mm] SPACING ±

3. SIDE LAPS SHALL BE A MIN OF 3" [76mm] AND END LAPS SHALL BE A MIN OF 6" [152mm]. STAG. ALL LAPS A MIN OF 12" [305mm] BETWEEN LAYERS, AND A MIN OF 24" [610mm] BETWEEN ROWS. TRIM THE UNDERLYING MEMBRANE AT A 45° ANGLE AT THE

FIELD & PERIMETER (ZONE 1 & 2)

4. APPLY ONE ADDITIONAL 3/4" [19mm] BEADS RUNNING LENGTHWISE AND SPACED EQUALLY OVER THE WIDTH OF THE BOARD, (12" [305mm] SPACING ±

5. APPLY THREE ADDITIONAL 3/4" BEADS RUNNING LENGTHWISE AND SPACED EQUALLY OVER THE WIDTH OF THE BOARD, (6" [152mm] SPACING ± 1-1/2"

