


GRANULAR PATHWAY OR



- TREES TO BE SET PLUMB. PRUNE AS SPECIFIED.

- REINFORCED RUBBER HOSE-LOOP AROUND STRONG STRUCTURE OF TREE

— 9-GAUGE STRANDED PLIABLE WIRE

— T-BAR STEEL STAKE TO CLEAR ROOT BALL

- ROOT FLARE SHALL BE AT, OR SLIGHTLY ABOVE FINISH GRADE. REMOVE EXCESS TOPSOIL FROM TOP OF ROOT BALL. DO NOT PLACE PLANTING SOIL OVER ROOT BALL.

- ±100mm DEPTH BARK NUGGET MULCH CONTINUOUS IN MULCH BED, MULCH MUST NOT CONTACT TREE TRUNK. MULCH BED MIN. 1.8m WIDE.

SAUCER SHALL BE SOAKED WITH WATER IMMEDIATELY AFTER PLANTING BURLAP TO BE REMOVED COMPLETELY

- PLANTING SOIL OR ALTERNATE SUITABLE FOR TREE GROWTH AS APPROVED BY FORESTRY AND PROJECT LANDSCAPE ARCHITECT. REFER TO

SPECIFICATIONS. - BLACK DIAMOND EDGER ALONG ALL SODDED EDGES. INSTALL AS PER MANUFACTURER'S SPECIFICATIONS.

CONTINUOUS TREE PLANTING BED SHALL BE DUG MINIMUM 3m DIAMETER x DEPTH OF ROOT BALL

- UNDISTURBED SUBSOIL SUITABLE FOR PLANT GROWTH

MIN 150mm DEPTH CLEAN DRAINAGE COURSE WRAPPED IN FILTER FABRIC SUITABLE TO APPLICATION. MIN 2% SLOPE TO DRY WELL

DRY WELL. DRAINAGE COURSE 300mmØ x 1.5m DEPTH FILLED WITH DRAIN STONE. 2% SLOPE TO DRY WELL.

- NOTES: EXAMINE ROOT BALL PRIOR TO EXCAVATION OF PLANTING HOLE TO SOURCE ROOT FLARE AND PRIMARY ROOTS WITHIN THE ROOT BALL. DEPTH OF HOLE SHOULD CORRESPOND TO PRIMARY ROOTS
- BEING WITHIN THE FIRST 150mm (6") OF SOIL. REMOVE EXCESS SOIL ON TOP OF ROOT FLARE / PRIMARY ROOTS PRIOR TO PLACING TREE IN HOLE.



TYPICAL CONIFEROUS TREE PLANTING IN CONTINUOUS MULCH BED N.T.S.

TREE TO BE SET PLUMB IN CENTRE OF TREE PIT

METAL 'T' STAKE ON ONE OR TWO SIDES AND GUYING STRAP (WHERE REQUIRED, ADJUST LOCATION WITH PREVAILING WINDS)

- TREE GUARD: 100mm DIA. x 600mm LENGTH WEEPING TILE MATERIAL SLICED AND WRAPPED AROUND BASE OF TREE

- ROOT FLARE SHALL BE AT OR SLIGHTLY ABOVE FINISH GRADE. REMOVE EXCESS TOPSOIL FROM TOP OF ROOT BAL. DO NOT PLACE PLANTING SOIL OVER ROOT BALL

- ±100mm DEPTH BARK NUGGET CHIP MULCH CONTINUOUS IN MULCH CIRCLE. MULCH MUST NOT CONTACT TREE TRUNK

- SAUCER SHALL BE SOAKED WITH WATER IMMEDIATELY AFTER PLANTING

- CUT WIRE BASKET, BEND BACK TOP LOOPS AND REMOVE BURLAP FROM TOP 1/3 OF ROOT BALL. REMOVE ALL TWINE AND NON-BIODEGRADABLE MATERIAL.

-FINISHED GRADE OF SOD TO MEET FINISHED GRADE OF MULCH CIRCLE

-FINISHED GRADE OF PLANTING SOIL/TOPSOIL TO MEET TOP OF ROOT BALL GRADE

-TREE PLANTING MEDIUM, REFER TO SPECIFICATIONS

– PLANTING SOIL OR COMPACTED CLEAN EARTH FILL SUITABLE FOR TREE GROWTH

– REMOVE ALL DELETERIOUS MATERIALS INCLUDING GARBAGE, RUBBLE, DEBRIS, GRAVEL, ETC.

- 300mm LONG EPOXY COATED DOWELS @ 600 O.C. - SAND SWEPT JOINT - CHARCOAL CONCRETE UNIT PAVER – 13mm SAND SETTING BED - REINFORCED CONCRETE

REINFORCED CONCRETE


CROSSWALK

- CROSSWALK
- 150mm MINIMUM COMPACTED GRANULAR BASE COURSE
- COMPACTED SUBGRADE

WULCH CIRCLE 1.8m ೆ ∞ ⊑≧ TREE PIT: 3.0m DIAMETER x 600mm DEPTH NOTES: EXAMINE ROOT BALL PRIOR TO EXCAVATION OF PLANTING HOLE TO SOURCE ROOT FLARE AND PRIMARY ROOTS WITHIN THE ROOT BALL. DEPTH OF HOLE SHOULD CORRESPOND TO PRIMARY ROOTS BEING WITHIN THE FIRST 150mm (6") OF SOIL. REMOVE EXCESS SOIL ON TOP OF ROOT FLARE / PRIMARY ROOTS PRIOR TO PLACING TREE IN HOLE.

3 TYPICAL DECIDUOUS TREE PLANTING IN SOD L3.0 N.T.S.





ISSUED FOR TENDER 2023-01-12 MN Date Revisions Scale 2023-01-12 NTS Designed By Drawn By Checked By MN MN/JW JW



